



DOC023.52.90642

BioTector B7000i Online TOC Analyzer

Advanced Configuration

09/2020, Edition 1

Section 1 Advanced configuration	3
1.1 Safety information	3
1.2 Set the average result	3
1.3 Save 24-hour average results	3
1.4 Configure the pressure test and flow test settings	3
1.5 Configure the zero calibration settings	4
1.6 Configure the span calibration settings	6
1.7 Set the number of days between service	7
1.8 Enable automatic zero calibrations after service	7
1.9 Set automatic calibrations and/or checks	8
1.10 Show the calibration curves	8
1.11 Configure the fault settings	10
1.12 Configure the reaction check settings	11
1.13 Set to demonstration mode	12
1.14 Set the oxidation analysis mode	12
1.15 Configure Oxidation Program 1	13
1.16 Configure Oxidation Program 2	15
1.17 Configure the Oxidation Program 3	16
1.18 Configure the cleaning program	18
1.19 Configure the reagent purge cycle	19
1.20 Configure the CO ₂ analyzer settings	20
1.21 Configure the cooler settings	20
1.22 Configure the ozone destructor	21
1.23 Hardware configuration	22
Section 2 4-20 mA output modes	23
2.1 Stream multiplex mode	23
2.2 Full multiplex mode	24
Section 3 Modbus register maps	27
3.1 Measurement registers	27
3.2 Measurement time registers	30
3.3 Sample status registers	35
3.4 Settings registers	35
3.5 Calibration registers	37
3.6 Diagnostics registers	38
3.7 Error, Warning and Notification registers	40
3.8 Status and external control registers	40

Section 1 Advanced configuration

1.1 Safety information

Refer to the installation manual for general safety information, hazard descriptions and precautionary labels descriptions.

1.2 Set the average result

Set the number of reactions included in the average result. The average result is the result that shows on the display and is saved to the reaction archive. Set when the result on the display is an average result or not an average result.

1. Select MAINTENANCE > SYSTEM CONFIGURATION > RESULT INTEGRATION.
2. Select an option.

Option	Description
RESULT INTEGRATION	Sets the number of TOC reaction results included in the average result (default: 3). The average result is the result that shows on the display and is saved to the reaction archive.
INTEGRATION LIMITS	<p>Sets when the TOC result that shows on the display is an average result and when the TOC result is not an average result. The first setting is the percent (%) band variation (default: 6%). The second setting is the absolute variation in mgC/L (default: 2.0).</p> <p>If the result is within the TOC INT LIMITS settings, the result that shows on the display is an average result. If the result is not within the TOC INT LIMITS settings, the result is not an average result. The result that shows on the display is the result for the last reaction.</p>

1.3 Save 24-hour average results

Save 24-hour average of the reaction results for each sample stream to the reaction archive.

Note: The reaction results for manual samples (grab samples) are not included in the average.

1. Select MAINTENANCE > SYSTEM CONFIGURATION > SEQUENCE PROGRAM > AVERAGE PROGRAM.
2. Select an option.

Option	Description
LOG AVERAGE	Saves a 24-hour average of the reaction results for each sample stream to the reaction archive (default: NO).
AVERAGE UPDATE	Sets the time the 24-hour average is saved to the reaction archive (default: 00:00).

1.4 Configure the pressure test and flow test settings

Set the start time for the pressure test and flow test. Set the fault and warning limits for the pressure test and flow test.

1. Select MAINTENANCE > SYSTEM CONFIGURATION > SEQUENCE PROGRAM > PRESSURE/FLOW TEST.
2. Select an option.

Option	Description
TIME	Sets the start time for the pressure test and flow test (default: 08:15). A pressure test identifies if there is a gas leak. A flow test identifies if there is a blockage in the gas exhaust or the sample out lines.
PRESSURE TEST FAULT	Sets the limit for a pressure test fault. A fault occurs (05_PRESSURE TEST FAIL) if the flow is more than the fault limit (default: 6.0 L/h). <i>Note: To disable the pressure test, select 0.0 L/h. When disabled, a 29_PRESSURE TEST OFF warning occurs. In addition, an "OFF" message shows on the display.</i>
PRESSURE TEST WARN	Sets the limit for a pressure test warning. A warning occurs (26_PRESSURE TEST WARN) if the flow is more than the warning limit (default: 4.0 L/h) but less than the fault limit. The warning limit is usually 30% less than the PRESSURE TEST FAULT setting. <i>Note: To disable the pressure test warning, select 0.0 L/h. When disabled, an "OFF" message shows on the display.</i>
PRESSURE CHCK FAULT	Sets the limit for a pressure check fault. The analyzer does a pressure check at the end of each reaction to identify if there is a gas leak. A fault occurs (06_PRESSURE CHCK FAIL) if the flow is more than the fault limit (default: 6.0 L/h) for the number of consecutive reactions selected in the PRESSURE CHCK COUNT setting. <i>Note: To disable the pressure check, select 0.0 L/h. When disabled, an "OFF" message shows on the display.</i>
PRESSURE CHCK COUNT	Sets the number of consecutive reactions before a pressure check fault occurs (default: 3).
FLOW WARNING	Sets the limit for a flow test warning. A warning occurs (22_FLOW WARNING – EX or 23_FLOW WARNING – SO) if the flow is less than the fault limit (default: 45 L/h).
REACTOR PURGE CHECK	Sets the time that the analyzer measures the oxygen gas flow during the two pressure releases that are done at the end of each analysis cycle (default: 4 seconds).
REACTOR PURGE BAND	Sets the limit for a reactor purge warning. If the oxygen gas flow is not within the fault limit during the first pressure release at the end of each analysis cycle for three consecutive times, a 128_REACT PURGE WARN occurs (default: ± 3.0 L/h). If the oxygen gas flow is not within the fault limit during the second pressure release and an oxygen gas flow problem was identified during the first pressure release of the same reactor purge cycle, a 129_REACT PURGE FAIL occurs.

1.5 Configure the zero calibration settings

Set the zero calibration settings (e.g., number of reactions done at each operation range) and the alarm limits for zero calibrations and zero checks. Show the history of changes to the zero adjust values.

1. Select MAINTENANCE > SYSTEM CONFIGURATION > SEQUENCE PROGRAM > ZERO PROGRAM.
2. Select an option.

Option	Description
ZERO PROGRAM	<p>Sets the number of reactions done at each operation range (1, 2 and 3) during a zero calibration or zero check (Default: 6, 0, 0). The three settings are for operation range 1, range 2 and range 3.</p> <p>Note: <i>The analyzer does the zero calibration and zero check reactions only at the operation range(s) that are not set to 0. The analyzer calculates the TOC zero adjust value for the operation ranges that are set to 0.</i></p>
ZERO PROGRAM MAX	<p>Sets the maximum number of zero reactions done at a specific range if the average zero reading is not within the ZERO BAND setting (default: 10).</p>
ZERO AVERAGE	<p>Sets the number of zero reactions included in the average value the analyzer uses to set the zero adjust values. The three settings are for operation range 1, range 2 and range 3 (e.g., 3, 0, 0).</p>
ZERO BAND	<p>Sets the limit for the difference between the average zero value and each zero reaction value included in the average zero value (default: ± 1.0 mgC/L). If the difference between the average zero value and one or more of the zero reaction values is higher than the fault limit, the analyzer does another zero reaction until the difference is within the fault limit. If the difference is not within the fault limit after the maximum number of reactions (ZERO PROGRAM MAX), a 42_ZERO CAL FAIL or 43_ZERO CHCK FAIL warning occurs.</p> <p>When a 42_ZERO CAL FAIL warning occurs, the analyzer does not change the zero adjust values. The analyzer continues to use the previous zero adjust values.</p> <p>If the difference is within the fault limit after the maximum number of reactions, the analyzer completes the zero cycle and changes the zero adjust values.</p> <p>Note: <i>The ZERO BAND setting is used to do a stability check on the first programmed range. For example, if the zero calibration result (ZC) is set to range 0, 3, 0, the calculation is done for Range 2. Change the ZERO BAND setting if the ZERO PROGRAM settings are changed or the analyzer will not become stable and a 42_ZERO CAL FAIL warning will not occur.</i></p> <p>Note: <i>If the analyzer completes the zero cycle on the operation range (e.g., range 1), the analyzer does not do a zero cycle on the other ranges.</i></p>
SERVICE ZERO	<p>Sets the measurement interval (default: 20 measurements) and the number of zero calibrations (default: 5) for the SET SERVICE ZERO. Refer to the SET SERVICE ZERO setting in Enable automatic zero calibrations after service on page 7.</p>

The history of changes to the zero adjust values shows below the menu options. The history includes the zero adjust values with the date, time, zero range and zero type (calibration or check).

Descriptions of the codes shown follow:

- ZC—Zero calibration result
- ZK—Zero check result
- ZM—Zero adjust value set manually

1.6 Configure the span calibration settings

Set the basic and advanced span calibration settings (e.g., the calibration standard concentrations, operation range and tolerance limits for span calibrations and span checks). Show the history of changes to the span adjust values.

1. Select MAINTENANCE > SYSTEM CONFIGURATION > SEQUENCE PROGRAM > SPAN PROGRAM.
2. Select an option.

Note: Some of the settings that follow are also changed on the CALIBRATION > SPAN CALIBRATION menu, which is used to change the basic span calibration settings.

Option	Description
SPAN PROGRAM	<p>Note: Do not change the default setting unless necessary. Changes can have a negative effect on the span adjust values.</p> <p>Sets the number of span reactions the analyzer does during a span calibration and a span check (default: 5).</p>
SPAN AVERAGE	<p>Note: Do not change the default setting unless necessary. Changes can have a negative effect on the span adjust values.</p> <p>Sets the number of reactions the analyzer uses to calculate the average value for the span adjust values (default: 3).</p>
RANGE	<p>Sets the operation range (1, 2 or 3) for span calibration reactions and span check reactions (default: 1). Select the operation range that agrees with normal measurements for the sample stream(s).</p> <p>Refer to the SYSTEM RANGE DATA screen to see the three operation ranges. Select OPERATION > SYSTEM RANGE DATA.</p> <p>Note: If the RANGE setting is not applicable to the STANDARD settings, the analyzer shows "CAUTION! REACTION RANGE OR STANDARD IS INCORRECT."</p>
TOC CAL STD TIC CAL STD	<p>Sets the concentrations of the TIC and TOC calibration standards for span calibrations (defaults: TIC = 50.0 mgC/L and TOC = 100.0 mgC/L). Enter concentrations that are 50% or more of the full scale value for the operation range selected in the RANGE setting. For example, if the operation range is 0 to 250 mgC/L, 50% of the full scale value is 125 mgC/L. If the calibration standard selected is 0.0 mg/L, the analyzer does not change the span adjust value for that parameter. In addition, the warning set with the TIC BAND and TOC BAND settings do not occur.</p> <p>Note: In VOC systems, do not do the TIC and TOC calibrations together. Do the TIC and TOC calibrations with different calibration standards.</p>
TC CAL STD	<p>Note: The TC CAL STD menu only shows in VOC systems.</p> <p>Shows the TC CAL STD value, which is the sum of the TIC CAL STD and TOC CAL STD.</p> <p>If the TOC CAL STD or TIC CAL STD setting is 0.0 mgC/L, the TC CAL STD is set to 0.0 mgC/L so that the analyzer does not change the span adjust value for TC. In addition, the warning set with the TC BAND setting does not occur.</p>
TIC CHECK STD	<p>Sets the concentrations of the TIC and TOC calibration standards for span checks (defaults: TIC = 25.0 mgC/L and TOC = 100.0 mgC/L).</p>
TOC CHECK STD	<p>If the calibration standard selected is 0.0 mg/L, the analyzer ignores the span check results. In addition, the warning set with the TIC BAND or TOC BAND settings do not occur.</p>

Option	Description
TC CHEK STD	<p><i>Note: The TC CHEK STD menu only shows in VOC systems.</i></p> <p>Shows the TC CHEK STD value, which is the sum of the TIC CHECK STD and TOC CHECK STD.</p> <p>If the TOC CHECK STD or TIC CHECK STD setting is 0.0 mgC/L, the TC CHEK STD is set to 0.0 mgC/L so that the analyzer ignores the span check results for TC. In addition, the warning set with the TC BAND setting does not occur.</p>
TIC BAND TOC BAND	<p>Sets the tolerance limits based on the last calibration (default: ± 25%) for the span calibration or span check results for TIC and TOC.</p> <p>If the average span result is not within the tolerance limits, a 30_TOC SPAN CAL FAIL, 31_TIC SPAN CAL FAIL, 33_TOC SPAN CHCK FAIL or 34_TIC SPAN CHCK FAIL warning occurs.</p>
TIC FACTOR = TOC	<p>Sets the TIC span adjust value to the same value as the TOC span adjust value. When the TOC span adjust value is changed, the TIC span adjust value is also changed. (Default: Yes, enabled)</p>

The history of changes to the span adjust values shows below the menu options. The history includes the span adjust values with the date, time, span range, span type (calibration or check) and the concentration of the standard solution.

Descriptions of the codes shown follow:

- SC—Span calibration result
- SK—Span check result
- SM—Span adjust set manually

1.7 Set the number of days between service

Set the number of days between service or reset the service counter.

1. Select MAINTENANCE > DIAGNOSTICS > SERVICE.
2. Select an option.

Option	Description
REACTION COUNTER	Shows the number of reactions.
SERVICE REQUIRED IN	<p>Sets the number of days before the 83_SERVICE TIME warning occurs (default: 180 days = 6 months).</p> <p><i>Note: The number of days on the service counter decreases when the analyzer is on, even when the analyzer is stopped.</i></p>
RESET SERVICE COUNTER	Sets the service counter to 180 (default). Select RESET SERVICE COUNTER after service is completed.

1.8 Enable automatic zero calibrations after service

Set the analyzer to automatically do zero calibrations after service is completed (when the service counter is reset).

1. Select MAINTENANCE > DIAGNOSTICS > SERVICE.
2. Select an option.

Option	Description
SET SERVICE ZERO	<p>Sets the analyzer to automatically do a number of zero calibrations (default: 5) at a set measurement interval (default: 20 measurements) after service is done.</p> <p>To unselect SET SERVICE ZERO, select RESET SERVICE ZERO.</p> <p>To change the number of zero calibrations done and the measurement interval, select MAINTENANCE > SYSTEM CONFIGURATION > SEQUENCE PROGRAM > ZERO PROGRAM > SERVICE ZERO.</p> <p>When service is done on some components, contamination can enter the component. The contamination can have an effect on measurements (e.g., in low range analyzers). A zero calibration should be done at intervals after service to adjust the zero offset values as the contamination is removed from the analyzer.</p> <p>Note: If the analyzer is stopped when SET SERVICE ZERO is set to on, the analyzer does a zero calibration when the analyzer is started, then starts measurements.</p>
RESET SERVICE ZERO	<p>Unselects the SET SERVICE ZERO option. If RESET SERVICE ZERO is selected during a zero calibration, the analyzer goes to online operation after the zero calibration is completed.</p>

1.9 Set automatic calibrations and/or checks

Set the days and time when the analyzer does a span calibration, span check, zero calibration and/or zero check.

Make sure to plumb the calibration standard before a span calibration or span check is started. Refer to the Installation and Operation Manual for instructions.

Note: Do not keep standard solutions for a long period of time. The concentration of standard solutions changes over time.

Note: The line equalization function of the analyzer can contaminate the calibration standard. Contact technical support to set line equalization to off.

1. Select MAINTENANCE > COMMISSIONING > AUTOCAL PROGRAM.
2. Select an option.

Option	Description
TIME	<p>Sets the time (hh:mm) the analyzer does a span calibration, zero calibration, span check or zero check each day (default: 00:00, disabled).</p>
MONDAY–SUNDAY	<p>Sets the days the analyzer does a span calibration, zero calibration, span check or zero check (default: - -, disabled).</p> <p>The first setting is the type of reaction. Options: Z (zero), S (span) or ZS (zero followed by span)</p> <p>The second setting selects a calibration or check. Options: CHECK or CAL</p> <p>For example, S CHECK sets the analyzer to do a span check. ZS CAL sets the analyzer to do a zero calibration and then a span calibration.</p>

1.10 Show the calibration curves

Set the number of decimal places that show in reaction results. Show the calibration curves for the three operation ranges for each parameter measured.

1. Select MAINTENANCE > SYSTEM CONFIGURATION > CALIBRATION DATA.
2. Select an option.

Option	Description
DECIMAL PLACES	Sets the number of decimal places that show in the reaction results on the display and saved to the reaction archive (0, 1, 2 or 3).
TOC CALIBRATION 1-3	Shows the calibration curves for each parameter and operation range. For example, select TOC CALIBRATION 1 to see the TOC calibration curve for operation range 1.
TIC CALIBRATION 1-3	<ul style="list-style-type: none">• First column—Number of calibration points• Second column—Calibration factors calculated from the calibration data• Third column—Concentration of the calibration standards.• Fourth column—Uncalibrated results measured and calculated from the CO₂ analyzer

1.11 Configure the fault settings

Set the conditions when faults and warnings occur. Do not change the settings.

1. Select MAINTENANCE > SYSTEM CONFIGURATION > FAULT SETUP.
2. Select an option.

Option	Description
LOW O2 FLOW TIME	Sets a time limit for low oxygen flow. A 01_LOW O2 FLOW - EX or 02_LOW O2 FLOW - SO fault occurs if the oxygen flow decreases more than 50% of the mass flow controller (MFC) set value for more than the LOW O2 FLOW TIME setting (default: 12s).
HIGH O2 FLOW TIME	Sets a time limit for high oxygen flow. A 03_HIGH O2 FLOW fault occurs if the oxygen flow increases more than 50% of the mass flow controller (MFC) set value during a reaction for more than the HIGH O2 FLOW TIME setting (default: 20s).
BASE CO2 ALARM	Sets the high CO ₂ limit for zero calibrations and zero checks. A 52_HIGH CO2 IN BASE warning occurs if the CO ₂ reading is higher than the BASE CO2 ALARM setting (default: 1000ppm). When a 52_HIGH CO2 IN BASE warning occurs, the analyzer sets the zero adjust values at the end of the completed zero calibration.
CO2 ZERO LINE	Sets the CO ₂ zero value for the analyzer zero step (default: 0 ppm). AUTO (default)—The analyzer sets the CO2 ZERO LINE value during the analyzer zero step. M (manual)—The CO2 ZERO LINE setting is used. For example, if there is a CO ₂ leak into the source or detector sections of the CO ₂ analyzer, a 400 ppm CO ₂ level in the environment will increase the CO2 ZERO LINE level to approximately 250 ppm within 24 days of online operation or after approximately 5000 reactions.
CO2 ZERO ALARM	Sets the CO ₂ alarm limit for the analyzer zero step (default: 250 ppm). A 12_HIGH CO2 IN O2 fault occurs if the CO ₂ measured at the analyzer zero step for the oxygen gas input is more than the CO2 ZERO LINE setting plus the CO2 ZERO ALARM setting for three consecutive reactions. The CO ₂ zero alarm limit identifies an oxygen concentrator failure. If the oxygen concentrator has a failure, the oxygen purity will decrease and CO ₂ at atmospheric levels (approximately 400 ppm) will enter the analyzer. If a defective oxygen concentrator is used, water can enter the analyzer with the oxygen gas, which can cause damage to the mass flow controller.
SERVICE COUNTER	Sets the number of days before the 83_SERVICE TIME warning occurs (default: 180 days). The number of days on the service counter decreases when the analyzer is on, even when the analyzer is stopped. Note: Changes to the MAINTENANCE setting will change the MAINTENANCE > DIAGNOSTICS > SERVICE > SERVICE REQUIRED IN setting.
OZONE TEST TIME	Sets the time limit for the ozone test (default: 18s). The maximum setting is 60 seconds.

Option	Description
SAMPLE STATUS	<p>Sets the maximum time for sample detection (default: 5s). Sets the limit for the percent (%) sample quality (default: 75%).</p> <p>The SAMPLE STATUS is set to on when there is no sample for more than the sample detection time or when the sample quality is less than the % sample quality limit. For example, when there is a significant quantity of air bubbles in the sample stream and/or manual grab sample tubing. The SAMPLE STATUS relay changes when the sample sensor signal is received and does not change between reactions or when the analyzer stops or goes to standby mode.</p> <p>Note: To disable sample detection, select 0 seconds.</p>
ARCHIVE	<p>Enables the 116/117/118/119/120/121_LOW/NO SAMPLE 1/2/3/4/5/6 notifications to occur when there is no or low sample liquid from the sample stream.</p>
SAMPLE FAULT 1 to 6	<p>Sets a time delay for the SAMPLE FAULT 1/2/3/4/5/6 relay and the 122/123/124/125/126/127_SAMPLE FAULT 1/2/3/4/5/6 notification (default: 100s). The time delay stops a sample fault that occurs for a short time from setting the SAMPLE FAULT 1 relay to on.</p>
AUTO RESET	<p>Sets the 122/123/124/125/126/127_SAMPLE FAULT 1/2/3/4/5/6 notification to be automatically acknowledged (YES) or to be acknowledged manually (NO, default).</p>
TEMPERATURE ALARM	<p>Sets the alarm limit for the analyzer temperature (default: 45 °C). A 53_TEMPERATURE ALARM warning occurs if the analyzer temperature is more than the alarm limit for more than 120 seconds.</p>
BACKUP BAT LOW	<p>Sets the 133_BACKUP BAT LOW to be a note, warning (default) or fault. A 133_BACKUP BAT LOW warning occurs when the backup battery on the motherboard is low.</p>

1.12 Configure the reaction check settings

Set the minimum CO₂ reading for a reaction. Set the CO₂ check limits for TIC analysis and TOC analysis. Do not change the settings.

1. Select MAINTENANCE > SYSTEM CONFIGURATION > REACTION CHECK.
2. Select an option.

Option	Description
CO2 LEVEL	<p>Sets the minimum CO₂ reading for a reaction. Because there is organic and inorganic contamination in the analyzer reagents, each TOC reaction will have a small CO₂ reading from the reagents even when there is no sample present.</p> <p>The first setting is the minimum CO₂ reading (default: 100 ppm). The second reading is the CO₂ level mode (default: AUTO). AUTO (default)—The analyzer sets the CO2 LEVEL setting to 60% of the average CO₂ peak reading from the last zero calibration or zero check. MAN—The analyzer uses the CO2 LEVEL setting.</p> <p>If a CO₂ peak occurs at the incorrect step of the reaction and/or if the CO₂ peak is less than the CO2 LEVEL setting for the number of reactions in the REACTION COUNT setting, a 04_NO REACTION warning or a 04_NO REACTION fault occurs.</p> <p>Note: To disable the reaction check, select 0 ppm. When set to 0 ppm, a reaction check will not be done when a zero calibration or zero check is done.</p>
FAULT TYPE	<p>Set the fault type of the 04_NO REACTION alarm. Options: FAULT or WARNING (default).</p>

Option	Description
REACTION COUNT	Sets the number of reactions for the 04_NO REACTION alarm (default: 3).
TIC CHECK	Sets the CO ₂ check limit in the TIC analysis (default: 25 ppm). If the CO ₂ level is more than the TIC CHECK setting at the end of the TIC analysis, the analyzer increases the TIC SPARGE TIME for 1 second, then identifies the CO ₂ reading again. If the CO ₂ is not less than the TIC CHECK value after 300 seconds, a 50_TIC OVERFLOW warning occurs.
TOC CHECK	Sets the CO ₂ check limit in the TOC analysis (default: 100 ppm). If the CO ₂ level is more than the TOC CHECK setting at the end of the TOC oxidation step, the analyzer increases the TOC SPARGE TIME and TOC OXIDATION time for 1 second, then identifies the CO ₂ reading again. If the CO ₂ is not less than the TOC CHECK value after 300 seconds, a 51_TOC OVERFLOW warning occurs.
TC CHECK	In VOC systems, sets the CO ₂ check limit in the TC analysis (default: 100 ppm). If the CO ₂ level is more than the TC CHECK setting at the end of the TC oxidation step, the analyzer increases the TC SPARGE TIME and TC OXIDATION time for 1 second, then identifies the CO ₂ reading again. If the CO ₂ is not less than the TC CHECK value after 300 seconds, a 51_TC OVERFLOW warning occurs.

1.13 Set to demonstration mode

Set the analyzer to operate in demonstration mode as necessary. In demonstration mode, the CO₂ peaks that show on the display are simulations. The analyzer does not use reagents or carrier gas to operate while in demonstration mode.

1. Select MAINTENANCE > SYSTEM CONFIGURATION > ANALYSIS MODE > DEMO MODE.
2. Select an option.

Option	Description
DEMO MODE	Sets demonstration mode to on. When OPERATION > START,STOP > START is selected, the analyzer operates in demonstration mode.
DEMO MODE CO2 DATA	Sets the height, width and time delays of the CO ₂ peaks that show on the display. CURVE PEAK —Sets the height of the CO ₂ peaks. CURVE WIDTH —Sets the width of the CO ₂ peaks. CURVE DELAY —Sets the time delays of the CO ₂ peaks.

1.14 Set the oxidation analysis mode

Set the oxidation analysis mode of a VOC system (TIC+TOC, TC or VOC).

Mechanical changes and system configuration changes are necessary to change the oxidation analysis mode if the analyzer is a TIC+TOC system. To set a specific analysis mode to on, the analyzer must be assembled and calibrated with the analysis mode at the factory.

Note: *If the analysis mode is changed, the analyzer changes several configuration settings to the default settings.*

1. Select MAINTENANCE > SYSTEM CONFIGURATION > ANALYSIS MODE > OXIDATION ANALYSIS.
2. Select an option.

Option	Description
TIC+TOC	Sets the analyzer to measure the TIC contents and then the TOC contents of a sample. Only one sample is added to the reactor.
TC	Sets the analyzer to measure the TC content of a sample. The analyzer only adds one sample to the reactor.
VOC	Sets the analyzer to do two reactions: TC analysis mode and then TIC+TOC analysis mode. Two samples are added to the reactor.

3. Manually change the analyzer settings with the supplied configuration printout.

1.15 Configure Oxidation Program 1

Only change the oxidation analysis settings for operation range 1 with the aid of technical support.

1. Select MAINTENANCE > SYSTEM CONFIGURATION > OXIDATION PROGRAM 1.
 - **TIC+TOC analysis mode**—Refer to [Table 1](#).
 - **TC analysis mode**—Refer to [Table 1](#) and [Table 2](#).
 - **VOC analysis mode**—Refer to [Table 1](#), [Table 2](#) and [Table 3](#).

Table 1 Oxidation Program 1—TIC+TOC settings

Option	Description
SAMPLE PUMP	Goes to MAINTENANCE > COMMISSIONING > SAMPLE PUMP. Refer to <i>Set the sample pump times</i> in the Installation and Operation Manual.
ANALYZER ZERO	Sets the analyzer zero time (default: 15s) and oxygen flow (default: 20 L/h). The CO ₂ analyzer identifies a zero offset level during the analyzer zero time. <i>Note: At the analyzer zero step, a 12_HIGH CO2 IN O2 fault occurs if the CO₂ analyzer reading is more than the CO2 ZERO LINE plus the CO2 ZERO ALARM value (default: 250 ppm) for three consecutive reactions.</i>
SAMPLE IN	Sets the quantity of sample (pulses) added to the reactor for operation range 1 (default: 11p). One pulse is ½ revolution of the pump roller. M–V (default)—Motorized-variable sample volume where the analyzer adds sample with the sample pump operation. M–F —Motorized-fixed volume sample volume where the analyzer adds sample with the 90° or 180° rotation of the sample (ARS) valve. For example, M-F90 and M-F180 sample injection types. <i>Note: Calibrate the analyzer after the SAMPLE IN setting is changed.</i>
TIC SPARGE TIME	Sets the TIC sparge time (default: 25s) and oxygen flow (default: 20 L/h). The analyzer sparges and measures the TIC content of the sample during the TIC sparge time. If the TIC level is not less than the TIC CHECK level (default: 100 ppm CO ₂) before the end of the TIC SPARGE TIME, the analyzer increases the time (extension time) until the TIC level is less than the 100 ppm level. <i>Note: A 50_TIC OVERFLOW warning occurs if the TIC level is not less than 100 ppm before the end of the maximum extension time (300s). The maximum extension time cannot be changed.</i>
TIC ACID	Sets the quantity of acid reagent (pulses) added to the reactor for the TIC sparge step for operation range 1 (default: 1p).
BASE OXIDATION	Sets the base oxidation time (default: 130s) and the oxygen flow (default: 10 L/h). The analyzer oxidizes the sample during the base oxidation time. <i>Note: If CO₂ is released during the base oxidation time, the CO₂ is measured and added to the TOC result because the default setting of RESULT INTEGRATION is TOC+BASE OXID in the RESULT INTEGRATION menu.</i>
BASE	Sets the quantity of base reagent (pulses) added to the reactor for operation range 1 (default: 7p).

Advanced configuration

Table 1 Oxidation Program 1—TIC+TOC settings (continued)

Option	Description
TOC SPARGE TIME	Sets the TOC sparge time (default: 135s) and oxygen flow (default: 20 L/h). The analyzer sparges and measures the TOC content of the sample during the TOC sparge time. If the TOC level is not less than the TOC CHECK level (default: 350 ppm CO ₂) before the end of the TOC SPARGE TIME, the analyzer increases the time (extension time) until the TOC level is less than the 350 ppm level. <i>Note: A 51_TOC OVERFLOW warning occurs if the TOC level is not less than 350 ppm before the end of the maximum extension time (default: 300s). The maximum extension time cannot be changed.</i>
TOC ACID	Sets the quantity of acid reagent (pulses) added to the reactor for the TOC sparge step for operation range 1 (default: 6p).
TOC OXIDATION	Sets the time the ozone generator operates at the start of the TOC sparge step (default: 60s). <i>Note: The TOC oxidation time is part of the TOC sparge step and does not increase the TOC sparge time.</i>
REACTOR PURGE	Set the reactor purge time (default: 47s). The analyzer removes the contents of the reactor during the reactor purge time. During the REACTOR PURGE phase, the system continuously monitors the oxygen gas flow with the mass flow controller (MFC). If a gas leak or a flow problem is sensed, a 06_PRESSURE CHCK FAIL or a 02_LOW O2 FLOW - SO system fault occurs.
PRESSURE CHECK	Sets the time and oxygen gas flow at which the mixer reactor is pressurized for the REACTOR PURGE phase (default: 20 second at 40 L/h).
PRESSURE RELEASE	Sets the time the analyzer opens the sample out valve (MV5) to release the pressure in the reactor when the gas flow is equal to or less than the PRESSURE CHCK FAULT level for more than 1 second during the PRESSURE CHECK phase (default: 12s at 45 L/h oxygen flow). Most of the liquid in the mixer reactor is removed through the sample out port. <i>Note: The PRESSURE CHCK FAULT level is set on the PRESSURE/FLOW TEST menu (default: 6.0 L/h).</i>
PRESSURE PURGE	Sets the time the mixer reactor is pressurized after the PRESSURE RELEASE phase is completed (default: 7s at 60 L/h oxygen flow).
PRESSURE RELEASE	Sets the time the analyzer opens the sample out valve (MV5) to release the pressure in the reactor after the PRESSURE PURGE phase is completed (default: 8s at 20 L/h oxygen flow). <i>Note: Unlike the first PRESSURE RELEASE phase, the motor of the mixer reactor is on during the second PRESSURE RELEASE phase. The remaining liquid in the mixer reactor is removed through the sample out port.</i>
CYCLES	Sets the number of times the PRESSURE PURGE and the PRESSURE RELEASE phases occur during the REACTOR PURGE phase (default: 1).
ANALYZER PURGE	Sets the analyzer purge time (default: 15s) and oxygen flow (default: 40L/h). The analyzer removes the contents of the CO ₂ analyzer during the analyzer purge time.
IDLE O2 FLOW	Sets the oxygen flow when the analyzer is in remote standby or is stopped (default: 1). The IDLE O2 FLOW setting supplies a small flow of oxygen through the system when the analyzer stopped to prevent damage to the oxygen pressure regulator.
REACTION TIME	Shows the total reaction time for operation range 1.

Table 2 Oxidation Program 1—TC settings

Option	Description
PRE OXIDATION	Sets the pre-oxidation time (default: 10s) and oxygen flow (default: 10 L/h). The pre-oxidation time is the initial oxidation step. During the initial oxidation step, hydroxyl radicals are made for the VOC oxidation step.
VOC OXIDATION	Sets the VOC oxidation time (default: 45s) and oxygen flow (default: 3 L/h). During VOC oxidation, the volatile organic carbon element of the sample oxidizes. <i>Note: VOC OXIDATION is set to 0 L/h to prevent the loss of volatiles before they are oxidized.</i>
ACID IN	Sets the quantity of acid reagent (pulses) added to the reactor for the VOC oxidation phase. (default: 1p)

Table 2 Oxidation Program 1—TC settings (continued)

Option	Description
TC SPARGE TIME	<p>Sets the TC sparge time (default: 135s) and oxygen flow (default: 20 L/h). The analyzer sparges and measures the TC content of the sample during the TC sparge time.</p> <p>If the TC level is not less than the TC CHECK level (default: 350 ppm CO₂) before the end of the TC SPARGE TIME, the analyzer increases the time (extension time) until the TC level is less than the 350 ppm level.</p> <p><i>Note: A 91_TC OVERFLOW warning occurs if the TC level is not less than 350 ppm before the end of the maximum extension time (default: 300s). The maximum extension time cannot be changed.</i></p>
TC ACID	Sets the quantity of acid reagent (pulses) added to the reactor for the TC sparge step for operation range 1 (default: 8p).
TC OXIDATION	Sets the time the ozone generator operates at the start of the TC Sparge phase (default: 60s). The TC OXIDATION time is part of the TC Sparge phase and does not increase the TC SPARGE TIME.

Table 3 Oxidation Program 1—VOC settings

Option	Description
SAMPLE PUMP FORWARD	Sets the forward operation time of the sample pump (default: 3s). The sample pump fills the sample (ARS) valve tubing with sample before the second sample injection into the reactor for the second TIC + TOC analysis reaction.

1.16 Configure Oxidation Program 2

Only change the oxidation analysis settings for operation range 2 with the aid of technical support.

- Select MAINTENANCE > SYSTEM CONFIGURATION > OXIDATION PROGRAM 2.
 - TIC+TOC analysis mode**—Refer to [Table 4](#).
 - TC analysis mode**—Refer to [Table 4](#) and [Table 5](#).
 - VOC analysis mode**—Refer to [Table 4](#) and [Table 5](#).

Table 4 Oxidation Program 2—TIC+TOC settings

Option	Description
RANGE CHANGE 1–2	<p>Sets the concentration levels used by the analyzer to change the operation range automatically from operation range 1 to operation range 2. The RANGE CHANGE 1–2 setting is usually 105% of the highest concentration of operation range 1 for TOC.</p> <p><i>Note: Refer to the SYSTEM RANGE DATA screen to see the three operation ranges. Select OPERATION > SYSTEM RANGE DATA.</i></p>
RANGE CHANGE 1–3	<p>Sets the concentration levels the analyzer uses to change the operation range automatically from operation range 1 to operation range 3. The RANGE CHANGE 1–3 setting is normally 175% of the highest concentration of operation range 1 for TOC.</p> <p><i>Note: Refer to the SYSTEM RANGE DATA screen to see the three operation ranges. Select OPERATION > SYSTEM RANGE DATA.</i></p>
RANGE CHANGE 2–1	<p>Sets the concentration levels used by the analyzer to change the operation range automatically from operation range 2 to operation range 1. The RANGE CHANGE 2–1 setting is normally 85% of the highest concentration of operation range 1 for TOC.</p> <p><i>Note: Refer to the SYSTEM RANGE DATA screen to see the three operation ranges. Select OPERATION > SYSTEM RANGE DATA.</i></p>

Table 4 Oxidation Program 2—TIC+TOC settings (continued)

Option	Description
SAMPLE IN	<p>Sets the quantity of sample (pulses) added to the reactor for operation range 2 (default: 6p). One pulse is ½ revolution of the pump roller.</p> <p>M–V (default)—Motorized-variable sample volume where sample is added with the sample pump operation.</p> <p>M–F—Motorized-fixed volume sample injection by the 90° or 180° rotation of the sample (ARS) valve. For example, M-F90 and M-F180 sample injection types.</p> <p><i>Note: Calibration the analyzer after the SAMPLE IN setting is changed.</i></p>
TIC ACID	Sets the quantity of acid reagent (pulses) added to the reactor for operation range 2 (default: 1p).
BASE	Sets the quantity of base reagent (pulses) added to the reactor for operation range 2 (default: 9p).
BASE OXIDATION	<p>Sets the base oxidation time (default: 150s). The analyzer oxidizes the sample during the base oxidation time for operation range 2.</p> <p><i>Note: If CO₂ is released during the base oxidation time, the analyzer adds the measured CO₂ to the TOC result because the default setting of RESULT INTEGRATION is TOC+BASE OXID in the RESULT INTEGRATION menu.</i></p>
TOC ACID	Sets the quantity of acid reagent (pulses) added to the reactor for the TOC sparge step for operation range 2 (default: 8p).

Table 5 Oxidation Program 2—TC settings

Option	Description
SAMPLE IN	<p>Sets the quantity of sample (pulses) added to the reactor for operation range 2 (default: 4p). One pulse is ½ revolution of the pump roller.</p> <p>M–V (default)—Motorized-variable sample volume where sample is added with the sample pump operation.</p> <p>M–F—Motorized-fixed volume sample injection by the 90° or 180° rotation of the sample (ARS) valve. For example, M-F90 and M-F180 sample injection types.</p> <p><i>Note: Calibration the analyzer after the SAMPLE IN setting is changed.</i></p>
ACID IN	Sets the quantity of acid reagent (pulses) added to the reactor for the VOC oxidation phase for operation range 2 (default: 2p).
TC ACID	Sets the quantity of acid reagent (pulses) added to the reactor for the TC sparge step for operation range 2 (default: 9p).

1.17 Configure the Oxidation Program 3

Only change the oxidation analysis settings for operation range 3 with the aid of technical support.

1. Select MAINTENANCE > SYSTEM CONFIGURATION > OXIDATION PROGRAM 3.
 - **TIC+TOC analysis mode**—Refer to [Table 6](#).
 - **TC analysis mode**—Refer to [Table 6](#) and [Table 7](#).
 - **VOC analysis mode**—Refer to [Table 6](#) and [Table 7](#).

Table 6 Oxidation Program 3—TIC+TOC settings

Option	Description
RANGE CHANGE 2–3	<p>Sets the concentration levels used by the analyzer to change the operation range automatically from operation range 2 to operation range 3. The RANGE CHANGE 2–3 setting is usually 105% of the highest concentration of operation range 2 for TOC.</p> <p>Note: Refer to the SYSTEM RANGE DATA screen to see the three operation ranges. Select OPERATION > SYSTEM RANGE DATA.</p>
RANGE CHANGE 3–2	<p>Sets the concentration levels used by the analyzer to change the operation range automatically from operation range 3 to operation range 2. The RANGE CHANGE 3–2 setting is normally 85% of the highest concentration of operation range 2 for TOC.</p> <p>Note: Refer to the SYSTEM RANGE DATA screen to see the three operation ranges. Select OPERATION > SYSTEM RANGE DATA.</p>
RANGE CHANGE 3–1	<p>Sets the concentration levels used by the analyzer to change the operation range automatically from operation range 3 to operation range 1. The RANGE CHANGE 3–1 setting is normally 85% of the highest concentration of operation range 1 for TOC.</p> <p>Note: Refer to the SYSTEM RANGE DATA screen to see the three operation ranges. Select OPERATION > SYSTEM RANGE DATA.</p>
SAMPLE IN	<p>Sets the quantity of sample (pulses) added to the reactor for operation range 3 (default: 0p).</p> <p>M–V —Motorized-variable sample volume where sample is added with the sample pump operation.</p> <p>MF–180 (default)—Motorized-fixed volume sample injection by the 180° rotation of the sample (ARS) valve.</p> <p>When SAMPLE IN is set to 0p, no sample is added to the reactor. Instead acid reagent (or base reagent) and oxygen gas is used to add the fixed volume of sample that is in the sample (ARS) valve.</p> <p>Note: Calibration the analyzer after the SAMPLE IN setting is changed.</p>
TIC ACID	Sets the quantity of acid reagent (pulses) added to the reactor for operation range 3 (default: 3p).
BASE	Sets the quantity of base reagent (pulses) added to the reactor at the base oxidation step for operation range 3 (default: 15p).
BASE OXIDATION	<p>Sets the base oxidation time (default: 150s) and the oxygen flow (default: 10 L/h). The analyzer oxidizes the sample during the base oxidation time.</p> <p>Note: If CO₂ is released during the base oxidation time, the CO₂ is measured and added to the TOC result because the default setting of RESULT INTEGRATION is TOC+BASE OXID in the RESULT INTEGRATION menu.</p>
TOC ACID	Sets the quantity of acid reagent (pulses) added to the reactor for the TOC sparge step for operation range 3 (default: 12p).

Table 7 Oxidation Program 3—TC settings

Option	Description
SAMPLE IN	<p>Sets the quantity of sample (pulses) added to the reactor for operation range 3 (default: 1p).</p> <p>M–V (default)—Motorized-variable sample volume where sample is added with the sample pump operation.</p> <p>MF–180 —Motorized-fixed volume sample injection by the 180° rotation of the sample (ARS) valve.</p> <p>When SAMPLE IN is set to 0p, no sample is added to the reactor. Instead acid reagent (or base reagent) and oxygen gas is used to add the fixed volume of sample that is in the sample (ARS) valve.</p> <p><i>Note: Calibration the analyzer after the SAMPLE IN setting is changed.</i></p>
ACID IN	<p>Sets the quantity of acid reagent (pulses) added to the reactor for the VOC oxidation phase for operation range 3 (default: 2p).</p>
TC ACID	<p>Sets the quantity of acid reagent (pulses) added to the reactor for the TC sparge step for operation range 3 (default: 12p).</p>

1.18 Configure the cleaning program

Configure the cleaning program to set the operation of the cleaning cycle. During the cleaning cycle, the sample pump operates in reverse to move the oxidized sample liquid from the catch-pot back through the sample inlet tubing and out of the analyzer.

1. Select MAINTENANCE > SYSTEM CONFIGURATION > SEQUENCE PROGRAM > CLEANING PROGRAM.
2. Select an option.

Option	Description
CLEANING TYPE	<p>Sets how the analyzer cleans the sample lines.</p> <p>REVERSE WASH—During the cleaning cycle, the sample pump operates in reverse and the cleaning valve opens to wash the sample lines with the oxidized sample in the catch-pot.</p> <p>FULL REACTION—During the cleaning cycle, the analyzer adds an external cleaning liquid to the reactor. The external cleaning liquid is oxidized with a full reaction cycle.</p> <p>REACTOR WASH—During the cleaning cycle, an external cleaning liquid is added to the mixer reactor and mixed for the REACTOR WASH TIME.</p> <p><i>Note: Analyzers with CLEANING TYPE set to REVERSE WASH cannot be set to FULL REACTION or REACTOR WASH. To change the cleaning type, mechanical and system configuration changes are necessary.</i></p> <p><i>Note: REVERSE WASH is disabled during zero calibration, span calibration and grab sample measurement.</i></p> <p><i>Note: REVERSE WASH is disabled during grab sample measurement if the MANUAL REVERSE setting is set to 0 seconds (default). To enable REVERSE WASH during grab sample measurement, the analyzer must have a Manual Bypass Valve to redirect the oxidized liquid in the catch-pot to the drain.</i></p>
CLEANING START	<p>Sets when a oxidation phase cleaning cycle is done. FIRST (default)—Before the number of reactions selected in CLEANING PERIOD, a cleaning cycle is done. LAST—After the number of reactions selected in CLEANING PERIOD, a cleaning cycle is done.</p>
CLEANING PERIOD	<p>Sets the number of reactions between each oxidation phase cleaning cycle (default: 1, 1). The first number is the number of reactions between each cleaning cycle. The second number is the number of cleaning cycles done.</p> <p><i>Note: To disable the cleaning cycle, select 0, 1.</i></p>

Option	Description
CLEANING VALVE	<p>Note: The <i>CLEANING VALVE</i> setting is not available when <i>CLEANING TYPE</i> is set to <i>REVERSE WASH</i>.</p> <p>SPF or SPF/SAMPLER—The cleaning valve is set to on just before and while the sample pump is operating in the forward direction.</p> <p>ON—The cleaning valve is set to on just after the sample pump completes the reverse operation.</p> <p>The cleaning valve is set to off when the injection into the reactor is completed.</p>
VALVE DELAY	<p>Note: The <i>VALVE DELAY</i> setting is not applicable when <i>CLEANING TYPE</i> is set to <i>FULL REACTION</i>.</p> <p>Sets the delay time before the cleaning valve opens (default: 0s). The delay time lets the analyzer empty the liquid sample that is between the bypass port and the cleaning valve during the <i>REVERSE WASH</i> cleaning cycle.</p>
CLEANING HIGH	Sets the number of reactions between each oxidation phase cleaning cycle when the TOC results is more than the <i>CLEANING HIGH AL</i> setting (default: 0).
CLEANING HIGH AL	Sets the TOC result for the <i>CLEANING HIGH</i> setting (default: 1000.0 mgC/L).
RANGE	<p>Note: The <i>RANGE</i> setting is not applicable when <i>CLEANING TYPE</i> is set to <i>REVERSE WASH</i>.</p> <p>Sets the operation range (e.g., Range 1) for the <i>FULL REACTION</i> and <i>REACTOR WASH</i> cleaning cycles. Sets the quantity of cleaning liquid added to the reactor.</p>
REACTOR WASH TIME	<p>Note: The <i>REACTOR WASH TIME</i> setting is not applicable when <i>CLEANING TYPE</i> is set to <i>REVERSE WASH</i> or <i>FULL REACTION</i>.</p> <p>Sets the time the cleaning liquid is mixed in the reactor during the <i>REACTOR WASH</i> cleaning cycle (default: 100s).</p>

1.19 Configure the reagent purge cycle

Configure the reagent purge settings. A reagent purge is done when *START NEW REAGENT CYCLE*, *PURGE REAGENTS & ZERO* or *RUN REAGENTS PURGE* is selected.

Do a reagent purge to move reagents through the reagent tubing to remove air bubbles and blockages.

1. Select *MAINTENANCE > SYSTEM CONFIGURATION > SEQUENCE PROGRAM > REAGENTS PURGE*.
2. Select an option.

Option	Description
ACID PURGE BASE PURGE	Sets the total operation time of the acid and base pumps to prime the reagents during the <i>INSTALL NEW REAGENTS</i> cycle and the number of reactor purge cycles that follow (default: 23s, 4).
TIC ACID FILL	Sets the quantity of acid reagent (pulses) added to prime the acid lines between the TOC acid valve and sample valve (default: 30p).
REACTOR ACID FILL	Set the quantity of acid reagent added to the reactor at the end of the <i>ACID&BASE PURGE</i> and <i>TIC ACID FILL</i> cycles (default: 12p).

Option	Description
REACTOR BASE FILL	Set the quantity of base reagent added to the reactor at the end of the ACID&BASE PURGE and TIC ACID FILL cycles (default: 18p).
REACTOR WASH TIME	Sets the time the acid and base reagents are mixed in the reactor during the REACTOR WASH TIME to balance the reactor pH and make the reactor pH neutral (default: 100s).

1.20 Configure the CO₂ analyzer settings

Set the connection type and baudrate for the CO₂ analyzer. Set the measurement range of the CO₂ analyzer. Set the zero and span calibration values to calibrate the CO₂ analyzer.

Only change the ANALYSIS GRAPH SCALE setting. Do not change the other settings.

1. Select MAINTENANCE > SYSTEM CONFIGURATION > CO₂ ANALYZER.
2. Select an option.

Option	Description
ANALYSIS GRAPH SCALE	Sets the full scale of the analysis graph on the Reaction Graph screen (default: 10000 ppm).
INTERFACE	Sets the connection type of the CO ₂ analyzer to analog (4–20 mA, default) or digital (RS232).
BAUDRATE	Sets the data communication signaling speed of the CO ₂ analyzer when INTERFACE is set to RS232 (default: 9600).
CO₂ ANALYZER RANGE	Sets the full scale range of the CO ₂ analyzer (default: 15000 ppm).
CO₂ ANALYZER CAL	Sets the CO ₂ analyzer range and the CO ₂ analyzer zero and span calibration values. Please contact technical support if changes to the calibration values are necessary.

1.21 Configure the cooler settings

Set the cooler setpoint temperature and operation mode. Set the cooler control operation.

1. Select MAINTENANCE > SYSTEM CONFIGURATION > COOLER PROGRAM.
2. Select an option.

Option	Description
COOLER	<p>Sets the cooler setpoint temperature (default: 16 °C) and the operation mode (default: DIFF).</p> <p>DIFF (differential temperature mode)—The cooler setpoint is the ambient temperature, which is the analyzer temperature minus the COOLER setting. For example, if the analyzer temperature is 20 °C, the cooler setpoint is 4 °C when the COOLER setting is 16 °C.</p> <p>F (fixed temperature mode)—The cooler setpoint is a fixed temperature (e.g., 5 °C).</p> <p>B(backup mode)—The cooler is controlled by the fixed PWM (pulse width modulation) operation.</p> <p><i>Note: The cooler operates in backup mode when a cooler fault occurs. A 54_COOLER LOW TEMP warning occurs if the cooler temperature is less than 2 °C (35.6 °F) for more than 600 seconds. A 55_COOLER HIGH TEMP warning occurs if the cooler temperature is 5 °C (9 °F) more than the cooler setpoint temperature and more than 8 °C (14 °F) below the ambient temperature for more than 600 seconds. Backup mode is cancelled when the fault is acknowledged.</i></p>
BACKUP PWM	<p>Sets the cooler control operation (default: 30%), which uses a PWM (pulse width modulation) period of 10 seconds to get to the cooler setpoint temperature for all of the cooler operation modes. For example, when BACKUP PWM is set to 30%, the cooler is set to on for 3 seconds and then set to off for 7 seconds.</p> <p>When a cooler fault occurs, the cooler operates in backup mode. In backup mode, the cooler is controlled by the fixed PWM operation. In backup mode, the COOLER settings and the temperature sensor information are ignored.</p>

1.22 Configure the ozone destructor

Set the operation mode for the ozone destructor heater.

1. Select MAINTENANCE > SYSTEM CONFIGURATION > OZONE DESTROY PROGRAM.
2. Select an option.

Option	Description
PURGE CYCLE MODE	<p>AUTO (default)—The ozone destructor heater and the cooler are controlled by the PURGE CYCLE FLOW and AUTO PURGE CYCLE settings.</p> <p>OFF—The ozone destructor heater and the cooler operate normally.</p> <p>MAN—The ozone destructor heater and the cooler are controlled by the MAN PURGE CYCLE setting.</p>
PURGE CYCLE FLOW	<p><i>Note: The PURGE CYCLE FLOW setting is only available when PURGE CYCLE MODE is set to AUTO.</i></p> <p>Sets a limit for the flow test (default: 77 L/h). When the flow measured during the flow test is less than the PURGE CYCLE FLOW setting, the ozone destructor heater and the cooler are controlled by the AUTO PURGE CYCLE setting.</p>

Advanced configuration

Option	Description
AUTO PURGE CYCLE	<p>Note: <i>The AUTO PURGE CYCLE setting is only available when PURGE CYCLE MODE is set to AUTO.</i></p> <p>The first setting is the number of analysis cycles the ozone destructor heater is set to off (default: 15). The second setting is the number of analysis cycles the ozone destructor heater and the cooler are set to off (default: 15).</p> <p>The analyzer uses the AUTO PURGE CYCLE settings after the flow test is done.</p>
MAN PURGE CYCLE	<p>Note: <i>The MAN PURGE CYCLE setting is only available when PURGE CYCLE MODE is set to MAN.</i></p> <p>The first setting is the number of analysis cycles the ozone destructor and the cooler operate as normal (default: 2000). The second parameter is the number of analysis cycles the ozone destructor heater is set to off (default: 15). The third setting is the number of analysis cycles the ozone destructor heater and cooler are set to off (default: 15).</p>

1.23 Hardware configuration

The MAINTENANCE > SYSTEM CONFIGURATION > HARDWARE CONFIGURATION menus are for factory use only.

Section 2 4-20 mA output modes

Set the 4–20 mA outputs to one of the three modes that follow:

- **DIRECT** (direct mode)—Each channel (4-20 mA output) shows a specified stream (STREAM 1) and result type (e.g., TOC).
- **STREAM MUX** (stream multiplex mode)—Channel 1 identifies the stream (e.g., STREAM 1). Channels 2 to 6 are configured to show one result type each (e.g., TOC). Channels 2 to 6 show the results for the streams in the OUTPUT 1 to 6 settings.
- **FULL MUX** (full multiplex mode)—Only four channels are necessary to show all of the result types from all of the streams. Channel 1 identifies the stream (e.g., STREAM 1). Channel 2 identifies the result type (e.g., TOC). Channel 3 shows the streams and result types in the OUTPUT 1 to 6 settings. Channel 4 shows the 24-average results for the streams and result types in the OUTPUT 1 to 6 settings.

A small amount of processing (normally with a programmable logic controller) is necessary when a multiplex mode is used.

2.1 Stream multiplex mode

In stream multiplex mode, Channel 1 (4–20 mA Output 1) changes its 4–20 mA signal at regular intervals to identify the sample stream or manual (grab sample) stream¹. Refer to [Table 8](#).

Channels 2 to 6 (4–20 mA Outputs 2 to 6) each show one result type (e.g., TIC, TOC) as configured in the CHANNEL settings. Refer to *Configure the 4–20 mA outputs* in the Installation and Operation Manual. Channels 2 to 6 change at 20 second intervals (default).

The sequence is as follows:

1. The 4-20mA READ relay is set to off. Channel 1 is set to 4 mA (change level).
2. Wait the configured time delay (SIGNAL HOLD TIME, default: 10 seconds).
3. Channels 2 to 6 show the sample stream results identified in the OUTPUT settings in the 4-20mA PROGRAM menu.
4. Channel 1 is set to the first sample stream (STREAM 1).
5. Wait 1 second.
6. The 4-20mA READ relay is set to on.
7. Wait the configured time delay (SIGNAL HOLD TIME, default: 10 seconds).
8. Steps 1 to 7 are done again for each sample stream (e.g., STREAM 2) and manual stream (MANUAL 1). When done, continue to step 9.
9. The 4-20mA READ relay is set to off. Channel 1 is set to 4 mA (change level).
10. Wait for a new result or the configured time (update period), then go to step 2.

Since the channel signals in stream multiplex mode change at regular intervals, it is necessary to get the analyzer and the external device that receives the channel signals synchronized. Use one of the two signals that follow to get the analyzer and the external device synchronized:

- Channel 1 (analog output)
- 4-20mA READ relay (digital output)

The 4-20mA READ relay is set to on 1 second after the 4–20 mA signals change on Channels 1–6. Configure one relay to be a 4-20mA READ relay, refer to *Configure the relays* in the Installation and Operation Manual.

When Channel 1 is set to 4 mA (change level) and the 4-20mA READ signal is set to off, the Channel 2 to 6 signals stay at the last value.

¹ The stream identification channel (Channel 1) identifies the sample stream for the first 10 seconds (default), then goes to 4 mA (change level) for 10 seconds (default).

Table 8 Channel 1 signals

Stream	Output	Stream	Output
Change level	4 mA	MANUAL 3	13 mA
STREAM 1	5 mA	MANUAL 4	14 mA
STREAM 2	6 mA	MANUAL 5	15 mA
STREAM 3	7 mA	MANUAL 6	16 mA
STREAM 4	8 mA	CAL	17 mA
STREAM 5	9 mA	CAL Z	18 mA
STREAM 6	10 mA	CAL S	19 mA
MANUAL 1	11 mA	Reserved	20 mA
MANUAL 2	12 mA		

2.2 Full multiplex mode

In full multiplex mode, only three 4–20 mA outputs are necessary to show all of the result types for all of the sample streams and manual (grab sample) streams.

Channel 1 (4–20 mA Output 1) changes its 4–20 mA signal at regular intervals to identify the sample stream or manual (grab sample) stream². Refer to [Table 8](#) on page 24.

Channel 2 (4–20 mA Output 2) changes its 4–20 mA signal at the same interval as Channel 1 to identify the result type³ (e.g., TIC). Refer to [Table 9](#).

Channel 3 (4–20 mA Output 3) is the INST result channel. Channel 3 shows the result at the end of each reaction for 20 seconds (default).

Channel 4 (4–20 mA Output 4) is the AVRG result channel. Channel 4 shows the 24-hour average result. The Channel 4 signal changes at the AVERAGE UPDATE time selected in SYSTEM CONFIGURATION > SEQUENCE PROGRAM > AVERAGE PROGRAM.

The sequence is as follows:

1. The 4-20mA READ relay is set to off. Channel 1 and Channel 2 are set to 4 mA (change level and not defined level).
2. Wait the configured time delay (SIGNAL HOLD TIME, default: 10 seconds).
3. Channel 2 is set to the first result type (TIC).
4. Channel 3 and 4 show the stream reaction result.
5. Channel 1 is set to the first sample stream (STREAM 1).
6. Wait 1 second.
7. The 4-20mA READ relay is set to on.
8. Wait the configured time delay (SIGNAL HOLD TIME, default: 10 seconds).
9. Steps 1 to 8 are done again for each result type. When done, continue to step 10.
10. Steps 1 to 9 are done again for each sample stream (e.g., STREAM 2) and manual stream (MANUAL 1). When done, continue to step 11.
11. The 4-20mA READ relay is set to off. Channel 1 and Channel 2 are set to 4 mA (change level and not defined level).
12. Wait for a new result or the configured time (update period), then go to step 2.

Since the channel signals in stream multiplex mode change at regular intervals, it is necessary to get the analyzer and the external device that receives the channel signals

² The stream identification channel (Channel 1) identifies the sample stream for the first 10 seconds (default), then goes to 4 mA (change level) for 10 seconds (default).

³ The result type channel (Channel 2) identifies the result type for the first 10 seconds (default), then goes to 4 mA (not defined level for 10 seconds).

synchronized. Use one of the two signals that follow to get the analyzer and the external device synchronized:

- Channel 1 (analog output)
- 4-20mA READ relay (digital output)

The 4-20mA READ relay is set to on 1 second after the 4–20 mA signals change on Channels 1–6. Configure one relay to be a 4-20mA READ relay, refer to *Configure the relays* in the Installation and Operation Manual.

When Channel 1 is set to 4 mA (change level) and the 4-20mA READ signal is set to off, the Channel 3 and 4 signals stay at the last value.

Table 9 Channel 2 signals

Result type	Output	Result type	Output
Not defined level	4 mA	BOD	10 mA
TIC	5 mA	LPI (lost product index)	11 mA
TOC	6 mA	LP (lost product)	12 mA
TC	7 mA	TOC kg/h	13 mA
VOC	8 mA	TOG (total oil and gas)	14 mA
COD	9 mA	Reserved	15 to 20 mA

Section 3 Modbus register maps

3.1 Measurement registers

Stream 1 measurements

Name	Description	Register	Data type
STREAM_1_RLOG_TIC	Stream 1: Last total inorganic carbon measurement	40001, 40002	float, read only -1.0 ⁶ to 1.0 ⁶
STREAM_1_RLOG_TOC	Stream 1: Last total organic carbon measurement	40003, 40004	
STREAM_1_RLOG_TC	Stream 1: Last total carbon measurement	40005, 40006	
STREAM_1_RLOG_VOC	Stream 1: Last volatile organic carbon measurement	40007, 40008	
STREAM_1_RLOG_COD	Stream 1: Last chemical oxygen demand measurement	40013, 40014	
STREAM_1_RLOG_BOD	Stream 1: Last biochemical oxygen demand measurement	40015, 40016	
STREAM_1_RLOG_LPI	Stream 1: Last calculated lost product index (%) result	40017, 40018	
STREAM_1_RLOG_LP	Stream 1: Last calculated lost product (L/h) result	40019, 40020	
STREAM_1_RLOG_FLOW	Stream 1: Last flow meter measurement	40021, 40022	
STREAM_1_RLOG_TW	Stream 1: Total waste result	40023, 40024	
STREAM_1_RLOG_CF	Stream 1: Last full cleaning reaction measurement	40027, 40028	

Note: When a register is read, the value in the `_TIME` register for that register (e.g., `STREAM_1_RLOG_TIC_TIME`) is updated.

Stream 2 measurements

Name	Description	Register	Data type
STREAM_2_RLOG_TIC	Stream 2: Last total inorganic carbon measurement	40029, 40030	float, read only -1.0 ⁶ to 1.0 ⁶
STREAM_2_RLOG_TOC	Stream 2: Last total organic carbon measurement	40031, 40032	
STREAM_2_RLOG_TC	Stream 2: Last total carbon measurement	40033, 40034	
STREAM_2_RLOG_VOC	Stream 2: Last volatile organic carbon measurement	40035, 40036	
STREAM_2_RLOG_COD	Stream 2: Last chemical oxygen demand measurement	40041, 40042	
STREAM_2_RLOG_BOD	Stream 2: Last biochemical oxygen demand measurement	40043, 40044	
STREAM_2_RLOG_LPI	Stream 2: Last calculated lost product index (%) result	40045, 40046	
STREAM_2_RLOG_LP	Stream 2: Last calculated lost product (L/h) result	40047, 40048	
STREAM_2_RLOG_FLOW	Stream 2: Last flow meter measurement	40049, 40050	
STREAM_2_RLOG_TW	Stream 2: Total waste result	40051, 40052	
STREAM_2_RLOG_CF	Stream 2: Last full cleaning reaction measurement	40055, 40056	

Note: When a register is read, the value in the `_TIME` register for that register (e.g., `STREAM_1_RLOG_TIC_TIME`) is updated.

Modbus register maps

Stream 3 measurements

Name	Description	Register	Data type
STREAM_3_RLOG_TIC	Stream 3: Last total inorganic carbon measurement	40057, 40058	float, read only -1.0 ⁶ to 1.0 ⁶
STREAM_3_RLOG_TOC	Stream 3: Last total organic carbon measurement	40059, 40060	
STREAM_3_RLOG_TC	Stream 3: Last total carbon measurement	40061, 40062	
STREAM_3_RLOG_VOC	Stream 3: Last volatile organic carbon measurement	40063, 40064	
STREAM_3_RLOG_COD	Stream 3: Last chemical oxygen demand measurement	40069, 40070	
STREAM_3_RLOG_BOD	Stream 3: Last biochemical oxygen demand measurement	40071, 40072	
STREAM_3_RLOG_LPI	Stream 3: Last calculated lost product index (%) result	40073, 40074	
STREAM_3_RLOG_LP	Stream 3: Last calculated lost product (L/h) result	40075, 40076	
STREAM_3_RLOG_FLOW	Stream 3: Last flow meter measurement	40077, 40078	
STREAM_3_RLOG_TW	Stream 3: Total waste result	40079, 40080	
STREAM_3_RLOG_CF	Stream 3: Last full cleaning reaction measurement	40083, 40084	

Note: When a register is read, the value in the *_TIME* register for that register (e.g., *STREAM_1_RLOG_TIC_TIME*) is updated.

Stream 4 measurements

Name	Description	Register	Data type
STREAM_4_RLOG_TIC	Stream 4: Last total inorganic carbon measurement	40085, 40086	float, read only -1.0 ⁶ to 1.0 ⁶
STREAM_4_RLOG_TOC	Stream 4: Last total organic carbon measurement	40087, 40088	
STREAM_4_RLOG_TC	Stream 4: Last total carbon measurement	40089, 40090	
STREAM_4_RLOG_VOC	Stream 4: Last volatile organic carbon measurement	40091, 40092	
STREAM_4_RLOG_COD	Stream 4: Last chemical oxygen demand measurement	40097, 40098	
STREAM_4_RLOG_BOD	Stream 4: Last biochemical oxygen demand measurement	40099, 40100	
STREAM_4_RLOG_LPI	Stream 4: Last calculated lost product index (%) result	40101, 40102	
STREAM_4_RLOG_CF	Stream 4: Last full cleaning reaction measurement	40105, 40106	

Note: When a register is read, the value in the *_TIME* register for that register (e.g., *STREAM_1_RLOG_TIC_TIME*) is updated.

Stream 5 measurements

Name	Description	Register	Data type
STREAM_5_RLOG_TIC	Stream 5: Last total inorganic carbon measurement	40107, 40108	float, read only -1.0 ⁶ to 1.0 ⁶
STREAM_5_RLOG_TOC	Stream 5: Last total organic carbon measurement	40109, 40110	
STREAM_5_RLOG_TC	Stream 5: Last total carbon measurement	40111, 40112	
STREAM_5_RLOG_VOC	Stream 5: Last volatile organic carbon measurement	40113, 40114	
STREAM_5_RLOG_COD	Stream 5: Last chemical oxygen demand measurement	40119, 40120	
STREAM_5_RLOG_BOD	Stream 5: Last biochemical oxygen demand measurement	40121, 40122	
STREAM_5_RLOG_LPI	Stream 5: Last calculated lost product index (%) result	40123, 40124	
STREAM_5_RLOG_CF	Stream 5: Last full cleaning reaction measurement	40127, 40128	

Note: When a register is read, the value in the *_TIME* register for that register (e.g., *STREAM_1_RLOG_TIC_TIME*) is updated.

Stream 6 measurements

Name	Description	Register	Data type
STREAM_6_RLOG_TIC	Stream 6: Last total inorganic carbon measurement	40129, 40130	float, read only -1.0 ⁶ to 1.0 ⁶
STREAM_6_RLOG_TOC	Stream 6: Last total organic carbon measurement	40131, 40132	
STREAM_6_RLOG_TC	Stream 6: Last total carbon measurement	40133, 40134	
STREAM_6_RLOG_VOC	Stream 6: Last volatile organic carbon measurement	40135, 40136	
STREAM_6_RLOG_COD	Stream 6: Last chemical oxygen demand measurement	40141, 40142	
STREAM_6_RLOG_BOD	Stream 6: Last biochemical oxygen demand measurement	40143, 40144	
STREAM_6_RLOG_LPI	Stream 6: Last calculated lost product index (%) result	40145, 40146	
STREAM_6_RLOG_CF	Stream 6: Last full cleaning reaction measurement	40149, 40150	

Note: When a register is read, the value in the *_TIME* register for that register (e.g., *STREAM_1_RLOG_TIC_TIME*) is updated.

3.2 Measurement time registers

Stream 1 measurement times

Name	Description	Register	Data type
STREAM_1_RLOG_TIC_TIME	Stream 1 Time and date of the last total inorganic carbon measurement	40300, 40301	integer, read only 0x00000000 to 0xFFFFFFFF
STREAM_1_RLOG_TOC_TIME	Stream 1 Time and date of the last total organic carbon measurement	40302, 40303	
STREAM_1_RLOG_TC_TIME	Stream 1 Time and date of the last total carbon measurement	40304, 40305	
STREAM_1_RLOG_VOC_TIME	Stream 1 Time and date of the last volatile organic carbon measurement	40306, 40307	
STREAM_1_RLOG_COD_TIME	Stream 1 Time and date of the last chemical oxygen demand measurement	40312, 40313	
STREAM_1_RLOG_BOD_TIME	Stream 1 Time and date of the last biochemical oxygen demand measurement	40314, 40315	
STREAM_1_RLOG_LPI_TIME	Stream 1 Time and date of the last calculated lost product index (%) result	40316, 40317	
STREAM_1_RLOG_LP_TIME	Stream 1 Time and date of the last calculated lost product (L/h) result	40318, 40319	
STREAM_1_RLOG_FLOW_TIME	Stream 1 Time and date of the last flow meter reading.	40320, 40321	
STREAM_1_RLOG_TW_TIME	Stream 1 Time and date of the last calculated total waste result.	40322, 40323	
STREAM_1_RLOG_CF_TIME	Stream 1 Time and date of the last full cleaning reaction measurement	40326, 40327	

Stream 2 measurement times

Name	Description	Register	Data type
STREAM_2_RLOG_TIC_TIME	Stream 2 Time and date of the last total inorganic carbon measurement	40328, 40329	integer, read only 0x00000000 to 0xFFFFFFFF
STREAM_2_RLOG_TOC_TIME	Stream 2 Time and date of the last total organic carbon measurement	40330, 40331	
STREAM_2_RLOG_TC_TIME	Stream 2 Time and date of the last total carbon measurement	40332, 40333	
STREAM_2_RLOG_VOC_TIME	Stream 2 Time and date of the last volatile organic carbon measurement	40334, 40335	
STREAM_2_RLOG_COD_TIME	Stream 2 Time and date of the last chemical oxygen demand measurement	40340, 40341	
STREAM_2_RLOG_BOD_TIME	Stream 2 Time and date of the last biochemical oxygen demand measurement	40342, 40343	
STREAM_2_RLOG_LPI_TIME	Stream 2 Time and date of the last calculated lost product index (%) result	40344, 40345	
STREAM_2_RLOG_LP_TIME	Stream 2 Time and date of the last calculated lost product (L/h) result	40346, 40347	
STREAM_2_RLOG_FLOW_TIME	Stream 2 Time and date of the last flow meter reading.	40348, 40349	
STREAM_2_RLOG_TW_TIME	Stream 2 Time and date of the last calculated total waste result.	40350, 40351	
STREAM_2_RLOG_CF_TIME	Stream 2 Time and date of the last full cleaning reaction measurement	40354, 40355	

Modbus register maps

Stream 3 measurement times

Name	Description	Register	Data type
STREAM_3_RLOG_TIC_TIME	Stream 3 Time and date of the last total inorganic carbon measurement	40356, 40357	integer, read only 0x00000000 to 0xFFFFFFFF
STREAM_3_RLOG_TOC_TIME	Stream 3 Time and date of the last total organic carbon measurement	40358, 40359	
STREAM_3_RLOG_TC_TIME	Stream 3 Time and date of the last total carbon measurement	40360, 40361	
STREAM_3_RLOG_VOC_TIME	Stream 3 Time and date of the last volatile organic carbon measurement	40362, 40363	
STREAM_3_RLOG_COD_TIME	Stream 3 Time and date of the last chemical oxygen demand measurement	40368, 40369	
STREAM_3_RLOG_BOD_TIME	Stream 3 Time and date of the last biochemical oxygen demand measurement	40370, 40371	
STREAM_3_RLOG_LPI_TIME	Stream 3 Time and date of the last calculated lost product index (%) result	40372, 40373	
STREAM_3_RLOG_LP_TIME	Stream 3 Time and date of the last calculated lost product (L/h) result	40374, 40375	
STREAM_3_RLOG_FLOW_TIME	Stream 3 Time and date of the last flow meter reading.	40376, 40377	
STREAM_3_RLOG_TW_TIME	Stream 3 Time and date of the last calculated total waste result.	40378, 40379	
STREAM_3_RLOG_CF_TIME	Stream 3 Time and date of the last full cleaning reaction measurement	40382, 40383	

Stream 4 measurement times

Name	Description	Register	Data type
STREAM_4_RLOG_TIC_TIME	Stream 4 Time and date of the last total inorganic carbon measurement	40384, 40385	integer, read only 0x00000000 to 0xFFFFFFFF
STREAM_4_RLOG_TOC_TIME	Stream 4 Time and date of the last total organic carbon measurement	40386, 40387	
STREAM_4_RLOG_TC_TIME	Stream 4 Time and date of the last total carbon measurement	40388, 40389	
STREAM_4_RLOG_VOC_TIME	Stream 4 Time and date of the last volatile organic carbon measurement	40390, 40391	
STREAM_4_RLOG_COD_TIME	Stream 4 Time and date of the last chemical oxygen demand measurement	40396, 40397	
STREAM_4_RLOG_BOD_TIME	Stream 4 Time and date of the last biochemical oxygen demand measurement	40398, 40399	
STREAM_4_RLOG_LPI_TIME	Stream 4 Time and date of the last calculated lost product index (%) result	40400, 40401	
STREAM_4_RLOG_CF_TIME	Stream 4 Time and date of the last full cleaning reaction measurement	40404, 40405	

Modbus register maps

Stream 5 measurement times

Name	Description	Register	Data type
STREAM_5_RLOG_TIC_TIME	Stream 5 Time and date of the last total inorganic carbon measurement	40406, 40407	integer, read only 0x00000000 to 0xFFFFFFFF
STREAM_5_RLOG_TOC_TIME	Stream 5 Time and date of the last total organic carbon measurement	40408, 40409	
STREAM_5_RLOG_TC_TIME	Stream 5 Time and date of the last total carbon measurement	40410, 40411	
STREAM_5_RLOG_VOC_TIME	Stream 5 Time and date of the last volatile organic carbon measurement	40412, 40413	
STREAM_5_RLOG_COD_TIME	Stream 5 Time and date of the last chemical oxygen demand measurement	40418, 40419	
STREAM_5_RLOG_BOD_TIME	Stream 5 Time and date of the last biochemical oxygen demand measurement	40420, 40421	
STREAM_5_RLOG_LPI_TIME	Stream 5 Time and date of the last calculated lost product index (%) result	40422, 40423	
STREAM_5_RLOG_CF_TIME	Stream 5 Time and date of the last full cleaning reaction measurement	40426, 40427	

Stream 6 measurement times

Name	Description	Register	Data type
STREAM_6_RLOG_TIC_TIME	Stream 6 Time and date of the last total inorganic carbon measurement	40428, 40429	integer, read only 0x00000000 to 0xFFFFFFFF
STREAM_6_RLOG_TOC_TIME	Stream 6 Time and date of the last total organic carbon measurement	40430, 40431	
STREAM_6_RLOG_TC_TIME	Stream 6 Time and date of the last total carbon measurement	40432, 40433	
STREAM_6_RLOG_VOC_TIME	Stream 6 Time and date of the last volatile organic carbon measurement	40434, 40435	
STREAM_6_RLOG_COD_TIME	Stream 6 Time and date of the last chemical oxygen demand measurement	40440, 40441	
STREAM_6_RLOG_BOD_TIME	Stream 6 Time and date of the last biochemical oxygen demand measurement	40442, 40443	
STREAM_6_RLOG_LPI_TIME	Stream 6 Time and date of the last calculated lost product index (%) result	40444, 40445	
STREAM_6_RLOG_CF_TIME	Stream 6 Time and date of the last full cleaning reaction measurement	40448, 40449	

3.3 Sample status registers

Name	Description	Register	Data type
RLOG_SMPL_STATUS	Sample status Quality of the sample, which is measured by the ultrasonic sensor	40200, 40201	float, read only 0.0 to 100.0
RLOG_SMPL_STATUS_TIME	Time and date of the last sample status measurement	40202, 40203	integer, read only 0x00000000 to 0xFFFFFFFF

Note: When a register is read, the value in the *_TIME* register for that register is updated.

3.4 Settings registers

Name	Description	Register	Data type	Min/Max
DEVICE_ADDR	DEVICE BUS ADDRESS setting	40500	integer, read/write	0x0000 to 0x00C8
DEVICE_ID	DEVICE ID setting	40501	integer, read/write	0x0000 to 0xFFFF
MANUF_ID	MANUFACTURE ID setting	40502	integer, read/write	0x0000 to 0x00FF

Modbus register maps

Name	Description	Register	Data type	Min/Max
DEVICE_SERIAL_ID	SERIAL NUMBER setting	40503, 40504, 40505	uint48, read only	0x000000000000 to 0xFFFFFFFFFFFFFF
PROTO_REV	Modbus protocol implementation revision rev AA.BB = 0xAABB	40506	integer, read only	0x0000 to 0x9999
FRMW_REV	FIRMWARE REV setting rev AA.BB = 0xAABB	40507	integer, read only	0x0000 to 0x9999
REGS_MAP_REV	REGISTERS MAP REV setting rev AA.BB = 0xAABB	40508	integer, read only	0x0000 to 0x9999
LOCATION_STR	LOCATION TAG setting <i>Note: Null terminate the string if there are less than 16 characters.</i>	40509, 40510, 40511, 40512, 40513, 40514, 40515, 40516	string, read/write	16 characters maximum
BAUDRATE	BAUDRATE setting 0 = 1200 bps 1 = 2400 bps 2 = 4800 bps 3 = 9600 bps 4 = 14400 bps 5 = 19200 bps 6 = 38400 bps 7 = 57600 bps 8 = 115200 bps	40517	integer, read/write	0x0000 to 0x0008
SYS_TIMEDATE ⁴	System time and date in seconds since January 1, 1970.	40518, 40519	integer, read/write	0x00000000 to 0xFFFFFFFF
SYS_TIME ⁴	System time in higher/lower bytes HH:MM = 0xHHMM	40520	integer, read/write	0x0000 to 0x3B3B
SYS_DATE ⁴	System date in 4 bytes Higher word DAY:MON = 0xDDMM Lower word YEAR = 0x0YYY	40521, 40522	integer, read/write	0x00000000 to 0x1F0C0833
REACT_TIC_RANGE1 ⁵	TIC range 1	40550, 40551	float, read only	0.0 to 1000000.0
REACT_TIC_RANGE2 ⁵	TIC range 2	40552, 40553		
REACT_TIC_RANGE3 ⁵	TIC range 3	40554, 40555		
REACT_TOC_RANGE1 ⁵	TOC range 1	40556, 40557		
REACT_TOC_RANGE2 ⁵	TOC range 2	40558, 40559		
REACT_TOC_RANGE3 ⁵	TOC range 3	40560, 40561		
REACT_TC_RANGE1 ⁵	TC range 1	40562, 40563		
REACT_TC_RANGE2 ⁵	TC range 2	40564, 40565		
REACT_TC_RANGE3 ⁵	TC range 3	40566, 40567		

⁴ This register cannot be changed until the system is fully stopped.

⁵ Shown as 0.0 if in the analysis mode for this result is not available.

3.5 Calibration registers

Name	Description	Register	Data type	Min/Max
AUTOCAL_PROG	Auto calibration day bit 0 = off bit 1 = Monday bit 2 = Tuesday bit 3 = Wednesday bit 4 = Thursday bit 5 = Friday bit 6 = Saturday bit 7 = Sunday	40700	integer, read only	0x0000 to 0x000F
AUTOCAL_PROG_TIME	Time of scheduled auto calibration in higher/lower bytes HH:MM = 0xHHMM	40701	integer, read only	0x0000 to 0x3B3B
CLOG_CAL_SELECT ⁶	Calibration type 0 = TIC 1 = TOC 2 = TC 3 = TN	40702	integer, read/write	0x0000 to 0x0004
CLOG_CAL1_SPAN_STATUS	Status of the last span calibration bit 0 = calibration bit 1 = check bit 2 = calibration successful bit 3 = result outside band bit 4 = calculated from other range bit 5 = calculated from TOC/TC result bit 6 = entered by operator Note: If a calibration failure occurs on the master range, it is necessary to update the derived results status also.	40703	integer, read only	0x0000 to 0x007F
CLOG_CAL2_SPAN_STATUS		40717		
CLOG_CAL3_SPAN_STATUS		40731		
Note: The CLOG_CALx register values are only updated when the associated CLOG_CALx_SPAN_STATUS register is read.				
CLOG_CAL1_SPAN_TIME	Time and date of the last span calibration	40704, 40705	integer, read only	0x00000000 to 0xFFFFFFFF
CLOG_CAL2_SPAN_TIME		40718, 40719		
CLOG_CAL3_SPAN_TIME		40732, 40733		
CLOG_CAL1_SPAN_STD	Calibration standard Note: Null if bits 4–6 are set in the _STATUS register.	40706, 40707	float, read only	-1.0 ⁶ to 1.0 ⁶
CLOG_CAL2_SPAN_STD		40720, 40721		
CLOG_CAL3_SPAN_STD		40734, 40735		

⁶ This register value changes the values of the CLOG registers that follow.

Modbus register maps

Name	Description	Register	Data type	Min/Max
CLOG_CAL1_SPAN_RSLT	Calibration results Note: Null if bits 4–6 are set in the _STATUS register.	40708, 40709	float, read only	-1.0 ⁶ to 1.0 ⁶
CLOG_CAL2_SPAN_RSLT		40722, 40723		
CLOG_CAL3_SPAN_RSLT		40736, 40737		
CLOG_CAL1_SPAN_FACTOR	Span adjustment factor	40710, 40711	float, read only	-1.0 ⁶ to 1.0 ⁶
CLOG_CAL2_SPAN_FACTOR		40724, 40725		
CLOG_CAL3_SPAN_FACTOR		40738, 40739		
CLOG_CAL1_ZERO_STATUS	Status of the last zero calibration bit 0 = zero calibration bit 1 = zero check bit 2 = zero successful bit 3 = result outside band bit 4 = calculated from other range bit 5 = TIC: no zero required bit 6 = entered by operator	40712	integer, read/write	0x0000 to 0x007F
CLOG_CAL2_ZERO_STATUS		40726		
CLOG_CAL3_ZERO_STATUS		40740		
CLOG_CAL1_ZERO_TIME	Time and date of the last zero calibration	40713, 40714	integer, read only	0x00000000 to 0xFFFFFFFF
CLOG_CAL2_ZERO_TIME		40727, 40728		
CLOG_CAL3_ZERO_TIME		40741, 40742		
CLOG_CAL1_ZERO_OFFSET	Zero offset	40715, 40716	float, read only	-1.0 ⁶ to 1.0 ⁶
CLOG_CAL2_ZERO_OFFSET		40729, 40730		
CLOG_CAL3_ZERO_OFFSET		40743, 40744		

3.6 Diagnostics registers

Name	Description	Register	Data type	Min/Max
OXF_ANLS	Shows the oxidation analysis type bit 0 = TIC+TOC bit 1 = TC bit 2 = VOC bit 3 = TIC+TOCe bit 4 = TCe	40586	integer, read only	0x0000 to 0x07FF
PANEL_TEMP	Temperature in the enclosure (°C)	40800, 40801	float, read only	-100.0 to 150.0
ATM_PRESS	Atmospheric pressure measurement from sensor (kPa)	40802, 40803	float, read only	0.0 to 250.0

Name	Description	Register	Data type	Min/Max
CO2A_ZERO ⁷	CO ₂ analyzer zero setting	40804, 40805	float, read only	-1.0 ⁶ to 1.0 ⁶
COOLER_TEMP	Cooler temperature (°C), if measured	40806, 40807	float, read only	-100.0 to 150.0
GCTRL_AIR_PRESSURE	Air pressure measured at the gas controller circuit board (kPa)	40812, 40813	float, read only	0.0 to 250.0
GCTRL_O2_PRESS	Oxygen pressure measured at the gas controller circuit board (kPa)	40814, 40815	float, read only	0.0 to 250.0
REACT_STREAM_VALVE	Analysis reaction stream valve 0 = no analysis on any stream valve 1 = analysis on Stream 1 valve 2 = analysis on Stream 2 valve 3 = analysis on stream 3 valve 4 = analysis on Stream 4 valve 5 = analysis on Stream 5 valve 6 = analysis on Stream 6 valve	40816	integer, read only	0 to 6
REACT_RANGE	Analysis reaction range 0 = no analysis reaction 1 = analysis reaction range 1 2 = analysis reaction range 2 3 = analysis reaction range 3	40817	integer, read only	0 to 3
ACID_RGNT_STATUS	Number of days of acid remaining	40818	integer, read only	0 to 999
BASE_RGNT_STATUS	Number of days of base remaining	40819	integer, read only	0 to 999
REACT_CNTR	Reaction counter	40824, 40825	integer, read only	0x00000000 to 0xFFFFFFFF
SERVICE_REQ	Number of days until service is necessary	40826	integer, read only	0x0000 to 0xFFFF

⁷ This register is set to 0.0 when power is set to on and is set to the correct value during the ANALYZER_ZERO reaction condition.

3.7 Error, Warning and Notification registers

For descriptions of the fault codes, refer to *Troubleshooting* in the Maintenance and Troubleshooting Manual.

Name	Description	Register	Data type	Min/Max
SYS_ALARM_STATUS	Alarm status bit 0 = fault bit 1 = warning bit 2 = notification bit 3 = Drinking water warning	49930	integer, read only	0x0000 to 0x000F
SYS_COND_GRP	bit 0 = fault 01_LOW O2 FLOW - EX bit 1 = fault 02_LOW O2 FLOW - SO ... bit 15 = fault 16_SAMPLE VALVE SEN3	49950		
SYS_COND_GRP	bit 0 = fault 17_SMPL VALVE NOT SYNC bit 1 = fault 18_LIQUID LEAK DET ... bit 15 = fault 33_TOC SPAN CHCK FAIL	49951		
...		
SYS_COND_GRP	bit 0 = fault 241 bit 1 = fault 242 ... bit 15 = fault 257	49965		

3.8 Status and external control registers

Name	Description	Register	Data type	Min/Max
SYS_OP_STATUS	Operation status bit 0 = normal operation bit 1 = manual operation bit 2 = calibration bit 3 = zero bit 4 = remote standby is activated bit 5 = maintenance switch is activated	49931	integer, read only	0x0000 to 0x003F
SYS_REM_CTRL	System remote control 0 = no change 1 = system finish and stop 2 = analysis start 3 = zero cal start 4 = zero check start 5 = span cal start 6 = span check start 7 = reagents purge and zero	49932	integer, read/write	0 to 7
SYS_REM_CTRL_STANDBY	Set Remote Standby function 0 = Modbus remote standby deactivated 1 = Modbus remote standby activated Note: The content of this register is internally ORed (boolean logic) with the Remote Standby digital input, if available.	49933	integer, read/write	0 to 1

Name	Description	Register	Data type	Min/Max
SYS_REM_CTRL_SYNC	Synchronization output for remote control operation Note: This register is enabled even when no SYNC output is identified.	49934	integer, read only	0 to 1
SYS_REM_CTRL_RANGE	Select next range 0 = not selected / auto 1 = range 1 2 = range 2 3 = range 3 Note: If this register value is 0, the range is selected with the EXT_RANGE_MUX1-2 digital inputs, if available. If the EXT_RANGE_MUX1-2 digital inputs are not available, the value of this register controls the digital input lines.	49935	integer, read/write	0 to 3
SYS_REM_CTRL_STREAM	Next stream to be selected bit 0 = Stream 1 bit 1 = Stream 2 bit 2 = Stream 3 bit 3 = Stream 4 bit 4 = Stream 5 bit 5 = Stream 6 Note: The content of this register is internally ORed (boolean logic) with the STREAM SEL 1-6 digital inputs to enable or disable stream selection.	49936	integer, read/write	0x0000 to 0x007f
SYS_DEBUG_MODE	System debug mode register 0 = normal system operation 1 = system supplies pre-defined Modbus registers values	45000	integer, read/write	0x0000 to 0x0001

HACH COMPANY World Headquarters

P.O. Box 389, Loveland, CO 80539-0389 U.S.A.
Tel. (970) 669-3050
(800) 227-4224 (U.S.A. only)
Fax (970) 669-2932
orders@hach.com
www.hach.com

HACH LANGE GMBH

Willstätterstraße 11
D-40549 Düsseldorf, Germany
Tel. +49 (0) 2 11 52 88-320
Fax +49 (0) 2 11 52 88-210
info-de@hach.com
www.de.hach.com

HACH LANGE Srl

6, route de Compois
1222 Vézenaz
SWITZERLAND
Tel. +41 22 594 6400
Fax +41 22 594 6499

