



XConnect Overview



Sutron Corporation
21300 Ridgetop Circle
Sterling, Virginia 20166
TEL: (703) 406-2800
FAX: (703) 406-2801
WEB: <http://www.sutron.com>

Bringing the Benefits of Real-Time Data Collection to the World

Sutro Sutron Corporation, 22400 Davis Drive, Sterling, Virginia 20164

Table Of Contents

- Welcome to XConnect 1
 - Features 1
- System Overview 3
 - XConnect Programs 3
 - XConnect Standard 3
 - XConnect Standard w/Database 3
 - XConnect Satellite 3
 - XConnect Satellite w/Database 4
 - XConnect ToolKit 4
 - XC Desktop 4
 - XC Setup 4
 - XC Rtu 4
 - XC RTDisplay 5
 - XC DataView 5
 - XC Mux 5
 - XC Decode 5
 - XC Daps 5
 - XC Reports/Reports Scheduler 6
 - XC PostProc 6
 - XC Calc 6
 - XC Export 6
 - XC Alarm 6
 - System Description 7
 - Master Station 7
 - Data Retrieval 7
 - Data Storage 7
 - Data Flow for Conventional Systems 8
 - Data Flow for Satellite Systems 8
- Getting Started 9
 - Installing XConnect Software 9
 - System requirements 9
 - Hardware 9
 - Software 9
 - Implementation -- A Few Examples 10
 - Software Startup 12
- Maintenance 15
 - Managing PcBase2 Data Files 15

- System Backup/Restore..... 15
- Getting Help..... 17
- Customer Support..... 17
 - Corporate Headquarters..... 17
 - Sales 17
 - Technical Support 17
- Using this Help System..... 19
 - Accessing the Help 19
 - Finding information in the Help..... 19
 - Moving around in the Help 20
 - Printing the Help 20
- Index 21

Welcome to XConnect

...realtime data from the field to your desktop.

XConnect is Sutron Corporation's latest data collection, data processing and data storage software. Built on the strong principles of PcBase2, XConnect is compliant with the 32-bit operating systems and provides new tools and options for the user.

Sutron's **XConnect** software puts data at your fingertips with a foundation built on a relational database, the most powerful open system for data collection, data processing and storage available. Internet access is greatly simplified when data is in an open database. XConnect supports storage to Oracle®, Access, SQL Server, so far... ODBC opens XConnect to support storage of HTML, XML, Java Applets, and stored procedures to enhance Internet applications.

Features

- Runs Under Windows 2000 and XP - Key modules are implemented as automation servers. Automation servers allow the exchange of methods and data among programs and development environments.
- Multiple Communication Protocol Support - XConnect communicates with the entire family of Sutron RTUs using SSP (Sutron Standard Protocol).
- Data time stamps set to the second. No separate files required for data with odd or random time intervals
- Optional real-time error detection flags on data items. Supports two thresholds of alarm detection plus "no change" checks. Items carry quality flags to tell which data items and calculations may be suspect.
- Communications diagnostics tools
- Flexible, scalable relational database (ORACLE, ACCESS, SQL SERVER, MYSQL, so far...)
- Intuitive user screens and tools
- Optional historical data tables





Wide variety of calculations before and after data storage including:

- Arbitrary Algebraic Operations
- Multiple Table Lookups (often used to convert stream depth to discharge)
- Automated Calculation and Storage of Statistics (MIN, MAX, SUM, MEAN, etc. post processing option)

System Overview

XConnect Programs

XConnect is organized into the following manner:

-  [XConnect Standard](#)
-  [XConnect Standard w/Database](#)
-  [XConnect Satellite](#)
-  [XConnect Satellite w/Database](#)
-  [XConnect Toolkit](#)

XConnect Standard

XConnect Standard represents the baseline XConnect package for a conventional system. A conventional system is defined by use of telephones, radios, or direct connect cables connected to the Sutron dataloggers. Conventional systems are two-way systems, where XConnect will send a data request to the Sutron datalogger and the datalogger will reply. The specific XConnect programs included are listed below. The data storage options are PcBase2 Binary files, ASCII log files, Excel files and XML files.

- [XC Desktop](#)
- [XC Setup](#)
- [XC Rtu](#)
- [XC RTDisplay](#)
- [XC DataView](#)

XConnect Standard w/Database

XConnect Standard w/Database includes all of XConnect Standard and expands the data storage options to include databases (Oracle™ and Access). Additional modules are included to assist the user in viewing and manipulating the data.

- [XConnect Standard](#)
- [XC Reports](#)
- [XC PostProc](#)
- [XC Calc](#)

XConnect Satellite

XConnect Standard represents the baseline XConnect package for a satellite system. A satellite system is defined by use of satellite transmitters (GOES or SATLINK transmitters) connected to the Sutron dataloggers. Satellite systems are one-way systems, where XConnect will communicate with a digital direct readout groupnd station (DDRGS)/receive site multiplexor to receive the satellite messages. The specific XConnect programs included are listed below. The data storage options are PcBase2 Binary files, ASCII log files, Excel files and XML files.

- [XC Desktop](#)
- [XC Setup](#)
- [XC Mux](#)

- [XC Decode](#)
- [XC Daps](#)
- [XC RTDisplay](#)
- [XC DataView](#)

XConnect Satellite w/Database

XConnect Satellite w/Database includes all of XConnect Satellite and expands the data storage options to include databases (Oracle™ and Access). Additional modules are included to assist the user in viewing and manipulating the data.

- [XConnect Satellite](#)
- [XC Reports](#)
- [XC PostProc](#)
- [XC Calc](#)

XConnect ToolKit

XConnect Toolkit option includes add-on utilities.

- [XC Export](#)
- [XC Alarm](#)

XC Desktop



XC Desktop is used to setup XConnect base stations. XC Desktop defines the stations, sensors, communication ports, poll groups and data storage. Other features of XC Desktop include the ability to import 8200/8210/XPert/XLite/8210. XC Desktop works with the XC Setup described below so that all XConnect programs can have access to setup parameters.

XC Setup



XC Setup provides setup information to all the XConnect programs that need it. XC Setup is designed to isolate XConnect applications from the details of how setup information is stored and accessed. This allows the setup information for any application to be modified locally or remotely by any other application using COM/DCOM. The current implementation of the XC Setup stores information in the file XConnect.INI in an ASCII format, similar to other Windows .INI files. Because applications often cache setup information in their own local memory, XC Setup supports a method of notifying applications that setup information has been changed.

XC Rtu



XC Rtu is responsible for all communications in **conventional systems**. Conventional systems are with Sutron RTUs with telephones, LOS radios and direct connections. XC Rtu supports automatic polling for archived or current data. As the messages are processed they are stored to disk and made available in XC Rtus database for real-time access. The data values are then available to other programs such as Wonderware Intouch for display, or XC RTDisplay or XC DataView.

XC Rtu also supports many manually initiated operation such as uploading and

downloading setups, starting and stopping RTUs, and other SSP operations. Uninitiated messages such as alarms are also supported. The XC Rtu features a polling display, protocol analyzer display and several message and status displays.

XC RTDisplay



XC RTDisplay real-time viewer of sensor data. XC RTDisplay monitors data, in real-time, from XC Rtu (for conventional systems) and XC Decode (for satellite systems) and displays the current values and time stamps for user selected sensor values.

XC DataView



XC DataView is used to view, graph, report and manipulate data stored in XConnect data storage options. XC DataView provides multiple graph styles and forms. Data can be manipulated and exported.

XC Mux



XC Mux is responsible for all communications to a Sutron Digital Direct Readout Ground Station (DDRGS) in a **satellite system**. XC Mux interfaces the PC to a Sutron DDRGS. The output of XC Mux is an ASCII file of satellite data compatible with XC Decode.

XC Decode



XC Decode is a program required in a **satellite system**. XC Decode automatically or manually reads in ASCII files of satellite data messages and extracts sensor values. As the values are decoded they are stored to disk and made available in XC Decode's database for real-time access. The data values are then available to other programs such as Wonderware Intouch for display, or XC RTDisplay or XC DataView. XC Decode uses XC Setup to obtain information on how to process each message that is received.

This program is obsolete. The NOAA/DAPS telnet site has been discontinued. Please see XC DDS as a replacement for XC Daps.

XC Daps



XC Daps is an optional program used in a **satellite system**. XC Daps automates a telnet sessions to the NOAA/DAPS sites. Each user that has received platform IDs/satellite IDs has a user account on the DAPS system. DAPS monitors and stores all satellite messages transmitted by all satellite IDs for 72 hours. Users can manually log in and download messages from the DAPS database if they do not have a DDRGS or the DDRGS is off-line.

XC Daps facilitates the download by automating the login and download commands. Like XC Mux, the output is an ASCII file of satellite data compatible with XC Decode.

XC DDS



XC DDS is an optional program used in a satellite system. XC DDS automates a tcp/ip session to a LRGS (Local Readout Ground Station) DDS server. This is the replacement method to the NOAA/DAPS telnet site. Users should contact Wallops CDA at 757-824-450, or by email at wcdadaps@noaa.gov to receive a user id and password. XC DDS facilitates the download by automating the login and download commands. Like XC Mux, the output is an ASCII file of satellite data compatible with XC Decode.

XC Reports/Reports Scheduler



XC Reports is an optional program used with the **database option**. XC Reports is a viewer/container for reports created by Crystal Reports. Crystal Reports is a popular report generation tool used widely throughout the world. Once the report is created in Crystal Reports, it can be added to the report library and accessed by XC Reports. XConnect comes with over 50 reports for view data and diagnostics.

Reports can also be generated on a schedule using XC Report Scheduler. With an intuitive interface, user can schedule reports to be generated automatically at a designate time and interval. The report can be stored to disk or sent directly to a printer.

XC PostProc



XC PostProc is an optional program used with the **database option**. XC PostProc perform post-processing of the sensor data stored in the database. XC PostProc reads data from the sensor data tables, processes averages, minimums or maximums and stores the computed/post-processed data in the post-processed data tables.

XC Calc



XC Calc is an optional program used with the **database option**. XC Calc is a flexible real-time general purpose, multi-value calculator. XC Calc connects automatically to a local or remote XConnect servers. XC Calc will connect to XC Decode and/or XC Rtu to receive data, compute user-defined equation and then store to the database.

XC Export



XC Export is an optional program used with the **database option**. XC Export exports data from the XConnect database, on a user-defined schedule, to ASCII, SHEF or Excel files. Exported data can be incorporated in reports, imported by other databases, or used for a variety of other purposes.

XC Alarm



XC Alarm is an optional program. When used with the **database option**, XC Alarm evaluates sensor thresholds and alarms. Thresholds are entered using XC Desktop and stored in the database. When XC Alarm detects that alarm thresholds are exceeded, the user can be notified by fax, email or text messages.

XC Alarm also allows the user to monitor XConnect applications and data. Hearbeat checks will be made to XConnect applications. Data continuity is checked in XC Rtu.

Also, database connectivity will also be monitored every minute. When database connectivity is restored, a ReInitialize will be sent to all the servers to re-connect to the database.

System Description

XConnect is a family of software programs designed to collect and process data from data collection platforms (DCPs) and remote terminal units (RTUs). XConnect runs on a master station PC and can work with stations using telephone modems, cellular data packet modems, line of sight radio, direct connect and satellite communications. The field stations will usually be Sutron field stations although other manufacturer stations are also supported for systems using GOES communications or ALERT format data communications.

Master Station

The typical master station consists of a PC with one or more communications devices for retrieving the data from the field. The master station PC system with its modems or communications ports handles all the functions to collect, process, store and display data. It also provides data to other PCs that may be used in a network.

The master station runs in the Microsoft Windows™ environment. Windows™ provides multitasking so the separate functions to collect, process and store data can all run at the same time. Windows provides DDE (Dynamic Data Exchange) and COM (Component Object Model) so the programs can communicate with each other and with third party software such as INTOUCH™ and EXCEL™. Sutron uses INTOUCH™, Delphi™ and Visual Basic™ to build custom real-time displays.


Data Retrieval

A typical master station is configured to either poll stations for data at some interval or wait for data to arrive by itself. **Conventional** (telephone and radio) systems are generally polled while **satellite** systems are not. The master station can be set to poll stations for either currently-sampled data or stored log data. The typical field station will store data every few minutes or every hour into its log. Many Sutron field stations can hold several months of data in memory and send it to the master station when polled. The satellite stations use both self-timed and random reporting modes to transmit the data to the master station. The data transmitted is usually that which was previously collected and stored in its log.


Data Storage

When the master station receives this data, XConnect stores it into the user-selected data storage option. Data storage options include PcBase2 binary files, ASCII log files, EXCEL™ files, and ACCESS™ or Oracle™ databases. XConnect provides multiple applications to view, graph and report the data.

Data Flow for Conventional Systems



Data Flow for Satellite Systems



Getting Started

Installing XConnect Software

In order to install **XConnect**:

1. Close all programs.
2. Insert the CD labeled **XConnect** into your CD-ROM drive. If Autorun is enabled on your system, the installation starts automatically and you can skip steps 3 and 4.
3. From the **Start** menu, select **Run**.
4. Type **D:\setup** (substitute the appropriate letter of your CD-ROM drive for D).
5. Follow the instructions on the screen.

By default, XConnect is installed in **C:\XConnect**.

System requirements

Hardware

The minimum hardware requirements are:

CPU:	Pentium III or later
Memory:	512MB or greater (1024 preferred)
Available disk space:	60MB

Software

The minimum software requirements are:

Operating System:	Windows 2000 or later
Other software:	Oracle, Access, SQL Server, MySQL (for database option)

Implementation -- A Few Examples

The following scenarios give some ideas of how XCONNECT can be used to implement a system. Note how the systems can be expanded by adding and configuring various XConnect modules.

Scenario 1: A system collects data from 20 telephone based Sutron loggers and stores the data into data files. Users display graphs and reports daily, weekly and monthly. **Details**

- XC Desktop was used to set up the master station. The setups from the loggers were imported to create the station setups. Data files were created and sensors were assigned to the data files. Poll groups were set up to control the polling for data and to synchronize the clocks of the loggers.
- XC Rtu runs continuously to poll the stations for data based on the poll schedule. XC Rtu process the incoming data and then stores it to the user-selected data storage option.
- XC Setup runs continuously to provide setup information to programs that request it. XC Setup also receives from XC Rtu changes to setup values that change with each poll.
- XC DataView is used to display the reports and graphs. Several different setting files have been saved -- one for the daily report, one for the weekly report and one for the monthly report.

This is a XConnect Standard or XConnect Standard w/Database system.

Scenario 2: The system in scenario one is expanded to use a remote workstation that will be able to display the reports. **Details**

- No changes are needed to the main PC because it already runs XC Rtu and has a modem, both of which are necessary for remote access.

On the remote PC,

- XC DataView is used to display the reports and graphs. In XC Dataview, use the menu change/create a data source. XC Dataview then displays the graphs and reports just like when it is used on local data.

XC DataView is included on all XConnect systems.

Scenario 3: The system is expanded by adding 5 Sutron based LOS radio stations. **Detail**

- A LOS modem is added to the master station.
- XC Desktop is used to configure the COM port for the LOS modem. The logger setups are imported and the sensors are added to the data files. A poll schedule is set up for the LOS stations.
- XC Rtu now will do both telephone and LOS polling and pass the data to XC Data.
- XC Rtu process the incoming data and then stores it to the user-selected data storage option.

This is a XConnect Standard or XConnect Standard w/Database system.

Scenario 4: The system is expanded to add 30 stations with GOES transmitters and a central receive site. **Details**

- The optional satellite software is needed for this expansion.

- XC Desktop is used to configure the XC MUX program and the COM port that connects it to the receive site. Import is used to read the logger setups and automatically set up the decoding for the stations. The new sensors are added to the data files.
- The XC Dataview reports are changed and saved to support the new stations.

This is a XConnect Satellite or XConnect Satellite w/Database system.

Software Startup

Configuring an XConnect system starts with XC Desktop. XC Desktop is the application where all XConnect servers are configured. XConnect servers denote data collection servers. As described in the [XConnect Programs](#) topic, many applications are a part of XConnect, servers and clients.

1. From the Windows Start Menu, select Programs|XConnect|XC Desktop. The first window to appear will ask the user to whether to connect to start XC Setup on the local PC or to connect to an XC Setup on a remote computer. ▶ If XC Setup is already running, the window will not appear.




Figure 1. Startup Connect window

XC Setup must always be running. All XConnect servers will start it automatically if it is not running. XC Setup will read the XConnect setup parameters and stored them in memory. XC Desktop only provides a graphical user interface (GUI) to these parameters.

2. If this is a new installation, XC Desktop will display a dialog box indicating this and will inform the user to start at the System Init window. ▶




Figure 2. New INI file message

3. The System Init window asks the user several basic question that configure a few underlying XConnect parameters. ▶

System Init

Is this a Conventional system using radio, modem, or direct connect?

Satellite Type

NONE GOES System INSAT System MSG System

Will you be using DDRGS hardware to receive NESDIS messages?

Will you be using XC DAPS (telnet) to receive NESDIS data?

Will you be connecting to an LRGS receiver to receive NESDIS data?

What type of Data Storage will be used?

None Access HDB (CADSWES)

PCBASE2 Binary files EXCEL files INSQL (WonderWare)

Oracle XML files

ASCII Log files SQL Server

Store all Real time data (Current polls/Satellite Random messages)?

Store all Time tag data (Date polls/Satellite Self-timed messages)?

Use a No Value Indicator? No Value Indicator:

Forward No Value Indicator

Figure 3. XC Desktop System Init window

- 4. Answer the questions according to your system requirements.

Maintenance

Managing PcBase2 Data Files

XConnect continues to support the older PcBase2 data file format. The data files contain the data collected by the system. The data files are created using XC Desktop. When they are created they are configured to hold data from certain sensors at selected intervals. Typical data files are:

RAIN.DAT	15 Minute Accumulated Rainfall from all the stations
BATTERY.DAT	Battery voltage from all the stations -- Hourly Data
COUNTER.DAT	Counter data from all the stations -- 15 minute data

The files have a start time and then continue to grow to as new data arrives. There is no limit on the size of the file other than available disk space.

System Backup/Restore

The tape backup software provided with the system has detailed instructions and strategies on system backup. Refer to the manuals for further information. If Sutron did not provide the Base Station hardware, then we strongly recommend that you perform system backups.

Getting Help

Customer Support

Corporate Headquarters

Sutron Corporation provides real-time data collection, telemetry, and technical expertise to monitor, control, manage, model, and forecast activities in areas of hydrology, meteorology, and water resource management.

Address:	Sutron Corporation 22400 Davis Drive Sterling, VA 20164 USA
Telephone:	703-406-2800
Fax:	703-406-2801
World Wide Web:	www.sutron.com
Office Hours:	Monday to Friday 8 am to 5 pm Eastern Standard Time

Sales

Contact your regional account representative for information about the latest products and services. Please visit our website at www.sutron.com for the latest contact information.

Technical Support

While most systems, software, and instruments can be installed and maintained by our customers, there are times when factory, field, or application engineering is needed. Any technical assistance required is available through telephone support, on-site expert service, and/or training. If you have additional questions, please do not hesitate to call us. Our sales engineers will advise the best solution for your situation.

Prior to calling, please have the following information available:

- Locate your product serial number or maintenance contract number.
- Determine your base station operating system version.
- Find the version of XC Setup in the About box.

Phone:	703-406-2800 (USA - corporate)
Fax:	703-406-2801 (USA - corporate)
Email:	support@sutron.com
Office hours:	8am to 5pm Eastern Standard Time

**24-hour World Wide Web
support:**

<http://www.sutron.com/support/default.htm>

Using this Help System

Accessing the Help

To find out more about how do something in XC Setup, access the online Help using any of the following methods.

To use the Contents, Index, or Search:

- From the **Help** menu, select **Contents & Index**. Use the buttons and [links](#) to navigate.

To get Help on a window or dialog:

- On any dialog, click the **Help** button.
- OR
- Press **F1** for help on any program window or dialog.
- OR
- Right-click and select **Help**.

Finding information in the Help

You can find information in the Help in several ways.

To find information in the online Help:

1. From the **Help** menu, click **XC Setup Help**.
2. If the left-hand pane isn't visible, click the **Contents**, **Index**, or **Search** buttons.
3. In the Help window, do the following:

Click:	To:
Contents	View the table of contents for the online Help. Click each book to display pages that link to topics, and click each page to display the corresponding topic in the right pane.
Index	Search for specific words or phrases or select from a list of index keywords. Click the keyword to display the corresponding topic in the right pane.
Search	Locate words or phrases within the content of your topics. Type the word or phrase in the text field, press ENTER , and select the topic you want from the list of topics.
Glossary	Display a list of words, short phrases, and their definitions related to Setup Server. When you select a term from the Term list, its corresponding definition is displayed in Definition .

Moving around in the Help

Use the following types of navigation in the Help to move around and display information (click the hotspots to read about each):

- **Hyperlinks:**
- **Related Topics:**
- **Drop-down text:**
- **Expanding text:**
- **Popups:**
- **Browse sequences:**

Printing the Help

While using online Help, you can print topics and information right from the browser window.

To print a Help topic:

1. Right-click in the right pane and select **Print**. The Print dialog opens.
2. Click **Print**. The topic is printed to the specified printer.

Index

A

ASCII SHEF3

C

Change Start Date 15

Corporate Headquarters 17

D

Data Files

 Managing 15

Data Files 15

DDE Batch 3

E

Email 17

H

Help

 Accessing 19

 Printing 20

 window 19

Help 19

Help 19

Help 20

Help menu 19

I

Installing

 XConnect Software 9

Installing 9

M

Maint button 15

Managing

 Data Files 15

N

Net DOS 3

O

Office Hours 17

Online Help 19

P

Poll ASCII 3

Poll DATA 3

Poll SHEF 3

S

Sales 17

Search 19

Software Startup 12

Split File 15

System Backup/Restore 15

System Overview 7

System requirements 9

T

Technical Support 17

W

Www.sutron.com 17

X

XC Setup Help 19

XCDData 3

XCDData Desktop 3, 15

XCDData Desktop Maintenance 15

XCDData Desktop's Select 15

XCDDecode 3

XCLogger 3

XCMUX 3

XConnect Software

 Installing 9

XConnect Software 9

XCOperator Desktop 3

XCRtu 3

XCSetup 3

XCSetup Desktop 3, 15