

# Diagnosing Ultra Low Range CL17sc Indicator Lights



Use this reference to diagnose Ultra Low Range CL17sc indicator lights. In the event of an amber or red status light, navigate to the analyser's diagnostics menu for more information.

**Hach Technical Support**  
[www.hach.com](http://www.hach.com)

## Three-Color Status Lights

---



Analyser is operating normally.



Analyser needs attention to prevent a future failure. Measurements will continue.



Analyser needs immediate attention. Measurements have stopped.

## Measurement Cycle Lights

---



Analyser is flushing the cell in preparation for a new measurement.



Analyser is adding and mixing reagents.



Analyser is performing a measurement.



Be Right™