



Compact all-in-one weather sensor with measurement of temperature, relative humidity, air pressure, wind direction, wind speed and radiation.

- **Parameters measured**
Temperature, relative humidity, air pressure, wind direction, wind speed, radiation
- **Measurement technology**
Ultrasonic/Wind, NTC/T, Capacitive/RH, MEMS capacitive/Pressure, Lufft Pyranometer/Radiation
- **Product highlights**
Wind detection with birdproof construction. Compact all-in-one weather sensor, low power, heater, aspirated radiation shield, maintenance-free operation, open communication protocol.
- **Interfaces**
RS485 with supported protocols UMB-Binary, UMB-ASCII, Modbus-RTU, Modbus-ASCII, XDR and SDI-12
- **Article number**
8375.2

From the WS product family of professional intelligent measurement transducers with digital interface for environmental applications. Integrated design with ventilated radiation protection for measuring: Air temperature, relative humidity, air pressure, wind direction, wind speed and radiation. One external temperature or rain sensor is connectable.

General

Technical Data

WS502-UMB Smart Weather Sensor



Dimensions	Ø approx. 150 mm, height approx. 317 mm
Weight	Approx. 1.5 kg
Interface	RS485, 2 - wire, half - duplex
Power supply	11...32 VDC
Power supply	5...11 VDC (electronics with limited precision of measurements)
Power supply	24 VDC +/- 10% (heater)
Power consumption	20 VA (heater)
Operating temperature	-50...60 °C (with heater)
Operating rel. humidity	0...100 % RH
Protection level housing	IP66
Standards/Regulations	Compliant to IEC 61724-1:2017 Class C
Mast mounting suitable for	Mast diameter 60 - 76 mm

Radiation

Unit	W/m ²
Accuracy	5 %
Response time (95%)	< 1 s
Non-stability(change/year)	±1 %
Non-linearity (0 to 1000 W/m ²)	±1 %
Directional error (at 80° with 1000 W/m ²)	±20 W/m ²
Temperature dependence of sensitivity	±5 % (-10 to +40 °C)
Tilt error (at 1000 W/m ²)	±1 %
Spectral range	300...1100 nm
Measuring range	1400 W/m ²

Temperature

Principle	NTC
Measuring range	-50 ... 60 °C
Unit	°C
Accuracy	±0.2 °C (-20...50 °C), otherwise ±0.5 °C (>-30 °C)

Relative humidity

Principle	Capacitive
Measuring range	0 ... 100 % RH
Unit	% RH
Accuracy	±2 % RH

Air pressure

Principle	MEMS capacitive
Measuring range	300 ... 1200 hPa
Unit	hPa
Accuracy	±0.5 hPa (0...40 °C)

Wind direction

Principle	Ultrasonic
Measuring range	0 ... 359.9 °
Unit	°
Accuracy	< 3 ° RMSE > 1.0 m/s
Resolution	0.1

Wind speed	
Principle	Ultrasonic
Measuring range	0 ... 75 m/s
Unit	m/s
Accuracy	±0.3 m/s or ±3 % (0...35 m/s) ±5 % (>35 m/s) RMS
Resolution	0.1 m/s