



# Uvas plus sc

## Sensor

The Uvas plus sc is a key contributor to the protection and control of your treatment process. Let the experts in Hach Service help you ensure that critical maintenance is done properly and on schedule to maximize performance and eliminate the risk of sensor damage and process upset.

### Benefits of Service

- Proper maintenance by certified Hach Service personnel prevents water infiltration and severe damage to the sensor
- Ensures peak performance and measurement accuracy
- Eliminates time and hassle of performing service and managing maintenance schedules
- Provides documentation to support regulatory compliance

*Annual Average Maintenance Time: Up to 4 hours*  
*Recommended Maintenance Frequency: 2x / year*

### Essential Maintenance Tasks Performed

#### Routine:

- Clean probe and measuring path and inspect for visible issues
- Replace wiper blade and bypass O-rings (if applicable)
- Calibrate with certified standard solutions to ensure accuracy
- Update firmware to the latest version

#### Advanced:

- Clean and inspect internal optical components
- Replace seals to prevent water infiltration that can result in severe damage to the sensor
- Replace desiccants to prevent condensation that can damage electronics and impact measurement accuracy
- Resolve any error or warning messages
- Produce service report and performance certificate

| Parts Replaced During Maintenance |                       |      |                              |        |                     |                                |           |           |
|-----------------------------------|-----------------------|------|------------------------------|--------|---------------------|--------------------------------|-----------|-----------|
| Part #                            | Description           | Qty. | Frequency                    | Part # | Description         | Qty.                           | Frequency |           |
| LZX426                            | Set of Seals          | 1    | 12 months                    | LZX302 | Desiccant, Set of 2 | 1                              | 12 months |           |
| LZX148                            | Wiper blades (5 pcs): | 1    | 24 months<br>(1 per service) | LZX303 | Desiccant           | 1                              | 12 months |           |
| LZX012                            |                       |      |                              | 1mm    | LZX572              | Bypass O-Rings (if applicable) | 1         | 12 months |
| LZX117                            |                       |      |                              | 2mm    |                     |                                |           |           |
| LZX119                            |                       |      |                              | 5mm    |                     |                                |           |           |
|                                   | 50mm                  |      |                              |        |                     |                                |           |           |

*These parts and replacement labor are included with a Hach Service Plan at the recommended frequency as long as the plan is renewed. Coverage is available for repairs on site or at the Hach Service Center.*

For more information, visit: [www.hach.com/service](http://www.hach.com/service)

**World Headquarters: Loveland, Colorado USA | [hach.com](http://hach.com)**

**United States** 800-227-4224 fax: 970-669-2932 email: [orders@hach.com](mailto:orders@hach.com)  
**Outside United States** 970-669-3050 fax: 970-461-3939 email: [int@hach.com](mailto:int@hach.com)