

Guidance for CL17sc in Wastewater Applications

Wastewater filtration options



Hayward 100µm
CPVC Simplex
Basket Strainer
\$822



Lakos 3/4" Model
T2C-075 105µm
Twist Clean Filter
~\$100



Hach Strainer
Kit, 100µm
Part #9623400
\$408



ISPRING
100µm Strainer
WSB100P
~\$200

Notes:

1. Y-strainer (40 mesh screen) provided with CL17sc is a sufficient filter for finished drinking water applications.
2. Other applications such as wastewater may require additional filtration for correct instrument operation, e.g., a coarse filter before the Y-strainer or a fine filter after the Y-strainer.
3. For some wastewater applications the flow meter may need to be bypassed. Will require 1/4" to 1/8" union #013861.